



FIPS 140-2 Security Policy

FortiGate-5140 Chassis with FortiGate 5000 Series Blades



<i>FortiGate-5140 Chassis with FortiGate 5000 Series Blades FIPS 140-2 Security Policy</i>		
Document Version:	2.2	
Publication Date:	October 25, 2012	
Description:	Documents FIPS 140-2 Level 2 Security Policy issues, compliancy and requirements for FIPS compliant operation.	
Firmware Version:	FortiOS 4.0, build8892, 111128	
Hardware Version:	FortiGate-5140 (C4GL51)	ADM-FB8 (P4FC12)
	FortiGate-5001SX (P4CF76-)	ASM-FB4 (AMC4F9)
	FortiGate-5001A-DW (P4CJ36-04)	Shelf Manager (PN 21594 346)
	FortiGate-5001A-SW (P4CJ36-02)	Alarm Panel (PN 21594 159)
	FortiGate-5001B (P4EV74)	



FortiGate-5140 Chassis with FortiGate 5000 Series Blades: FIPS 140-2 Security Policy

25 October 2012

01-430-159559-20111220

for FortiOS 4.0 MR3


© Copyright 2012 Fortinet, Inc.

This document may be freely reproduced and distributed whole and intact including this copyright notice.

Trademarks

Dynamic Threat Prevention System (DTPS), APSecure, FortiASIC, FortiBIOS, FortiBridge, FortiClient, FortiGate®, FortiGate Unified Threat Management System, FortiGuard®, FortiGuard-Antispam, FortiGuard-Antivirus, FortiGuard-Intrusion, FortiGuard-Web, FortiLog, FortiAnalyzer, FortiManager, Fortinet®, FortiOS, FortiPartner, FortiProtect, FortiReporter, FortiResponse, FortiShield, FortiVoIP, and FortiWiFi are trademarks of Fortinet, Inc. in the United States and/or other countries. The names of actual companies and products mentioned herein may be the trademarks of their respective owners.





Contents

Overview	2
References	2
Introduction	3
Security Level Summary	3
Module Description	4
Chassis Descriptions	4
Blade Descriptions	4
AMC Module Descriptions	5
Cryptographic Module Ports and Interfaces	6
FortiGate-5001SX Blade	6
FortiGate-5001A-DW and SW Blades	7
FortiGate-5001B Blade	9
ADM-FB8 AMC Component	11
ASM-FB4 AMC Component	12
FortiGate-5140 Chassis	13
Web-Based Manager	14
Command Line Interface	15
Roles, Services and Authentication	15
Roles	15
FIPS Approved Services	16
Authentication	17
Physical Security	18
Operational Environment	20
Cryptographic Key Management	20
Random Number Generation	20
Key Zeroization	20
Algorithms	21
Cryptographic Keys and Critical Security Parameters	21
Alternating Bypass Feature	23
Key Archiving	23
Electromagnetic Interference/Electromagnetic Compatibility (EMI/EMC)	23
Mitigation of Other Attacks	24
FIPS 140-2 Compliant Operation	24
Enabling FIPS-CC mode	25
Self-Tests	26
Non-FIPS Approved Services	26

Overview

This document is a FIPS 140-2 Security Policy for Fortinet Incorporated's FortiGate-5140 chassis with the FortiGate-5001SX, 5001A-DW, 5001A-SW and 5001B blade based Multi-Threat Security Systems. This policy describes how the FortiGate-5001SX, 5001A-DW, 5001A-SW and 5001B blades, when installed in the FortiGate-5140 chassis (hereafter referred to in combination as the 'module' or 'modules'), meet the FIPS 140-2 security requirements and how to operate the modules in a FIPS compliant manner. This policy was created as part of the Level 2 FIPS 140-2 validation of the modules.

This document contains the following sections:

- [Introduction](#)
- [Security Level Summary](#)
- [Module Description](#)
- [Mitigation of Other Attacks](#)
- [FIPS 140-2 Compliant Operation](#)
- [Self-Tests](#)
- [Non-FIPS Approved Services](#)

The Federal Information Processing Standards Publication 140-2 - *Security Requirements for Cryptographic Modules* (FIPS 140-2) details the United States Federal Government requirements for cryptographic modules. Detailed information about the FIPS 140-2 standard and validation program is available on the NIST (National Institute of Standards and Technology) website at <http://csrc.nist.gov/groups/STM/cmvp/index.html>.

References

This policy deals specifically with operation and implementation of the module in the technical terms of the FIPS 140-2 standard and the associated validation program. Other Fortinet product manuals, guides and technical notes can be found at the Fortinet technical documentation website at <http://docs.forticare.com>.

Additional information on the entire Fortinet product line can be obtained from the following sources:

- Find general product information in the product section of the Fortinet corporate website at <http://www.fortinet.com/products>.
- Find on-line product support for registered products in the technical support section of the Fortinet corporate website at <http://www.fortinet.com/support>
- Find contact information for technical or sales related questions in the contacts section of the Fortinet corporate website at <http://www.fortinet.com/contact>.
- Find security information and bulletins in the FortiGuard Center of the Fortinet corporate website at <http://www.fortinet.com/FortiGuardCenter>.

Introduction

The FortiGate product family spans the full range of network environments, from SOHO to service provider, offering cost effective systems for any size of application. FortiGate appliances detect and eliminate the most damaging, content-based threats from email and Web traffic such as viruses, worms, intrusions, inappropriate Web content and more in real time — without degrading network performance. In addition to providing application level firewall protection, FortiGate appliances deliver a full range of network-level services — VPN, intrusion prevention, web filtering, antivirus, antispam and traffic shaping — in dedicated, easily managed platforms.

All FortiGate appliances employ Fortinet's unique FortiASIC™ content processing chip and the powerful, secure, FortiOS™ firmware achieve breakthrough price/performance. The unique, ASIC-based architecture analyzes content and behavior in real time, enabling key applications to be deployed right at the network edge where they are most effective at protecting enterprise networks. They can be easily configured to provide antivirus protection, antispam protection and content filtering in conjunction with existing firewall, VPN, and related devices, or as complete network protection systems. The modules support High Availability (HA) in both Active-Active (AA) and Active-Passive (AP) configurations.

FortiGate appliances support the IPSec industry standard for VPN, allowing VPNs to be configured between a FortiGate appliance and any client or gateway/firewall that supports IPSec VPN. FortiGate appliances also provide SSL VPN services using TLS 1.0 in the FIPS-CC mode of operation.

Security Level Summary

The modules meet the overall requirements for a FIPS 140-2 Level 2 validation.

Table 1: Summary of FIPS security requirements and compliance levels

Security Requirement	Compliance Level
Cryptographic Module Specification	2
Cryptographic Module Ports and Interfaces	3
Roles, Services and Authentication	3
Finite State Model	2
Physical Security	2
Operational Environment	N/A
Cryptographic Key Management	2
EMI/EMC	2
Self-Tests	2
Design Assurance	3
Mitigation of Other Attacks	2

Module Description

The FortiGate modules (the blades and chassis in combination) are multiple chip, standalone cryptographic devices consisting of production grade components contained in a physically protected enclosure in accordance with FIPS 140-2 Level 2 requirements.

The blades run the FortiOS firmware, perform all of the cryptographic functions and provide the input/output interfaces. The chassis provide power, cooling and physical protection for the modules as a whole. The chassis do not run FortiOS firmware.

The modules are Internet devices that provide integrated firewall, VPN, antivirus, antispam, intrusion prevention, content filtering and traffic shaping capabilities. This FIPS 140-2 Security Policy specifically covers the firewall, IPSec and SSL-VPN capabilities of the modules.

The antivirus, antispam, intrusion prevention, content filtering and traffic shaping capabilities of the modules can be used without compromising the FIPS approved mode of operation.

The FortiGate-5001SX, 5001A-SW, 5001A-DW and 5001B blades are multiple chip, standalone cryptographic modules consisting of production grade components contained in a physically protected enclosure (the FortiGate-5140 chassis) in accordance with FIPS 140-2 Level 2 requirements.

The modules are Internet devices that provide integrated firewall, VPN, antivirus, antispam, intrusion prevention, content filtering and traffic shaping and HA capabilities. This FIPS 140-2 Security Policy specifically covers the firewall, IPSec and SSL-VPN capabilities of the modules.

The antivirus, antispam, intrusion prevention, content filtering and traffic shaping capabilities of the modules can be used without compromising the FIPS approved mode of operation.

The validated firmware version is FortiOS 4.0, build 8892, 111128.

Chassis Descriptions

The FortiGate-5140 has 3 hot swappable, internal ventilation fan units that draw in air from the bottom front of the chassis and expel it from the top rear. These fans are excluded from the requirements of FIPS 140-2, as they provide no security relevant function.

The FortiGate-5140 supports uses two, hot-swappable, DC power entry modules (PEMs). These PEMs are excluded from the requirements of FIPS 140-2, as they provide no security relevant function.

The FortiGate-5140 chassis uses an external DC power source.

The FortiGate-5140 chassis supports removable Shelf Manager (2) and Shelf Alarm (1) panels. One Shelf-Manager and one Alarm Panel are installed by default.

The FortiGate-5140 chassis includes slots for rear-panel blades. However, the rear panel slots are not populated in the validated configuration.

Blade Descriptions

The blades have a similar appearance and perform the same functions, but have different numbers and types of network interfaces in order to support different network configurations:

The FortiGate-5001SX blade has:

- 8 Gigabit network interfaces with a status LED for each interface (4 Gigabit SFP, 4 10/100/1000 BaseT)
- 2 x86 compatible CPUs
- 1 DB-9 Serial (console) port
- 2 USB ports

The FortiGate-5001A-DW blade has:

- 2 network interfaces with a status LED for each network interface (2 10/100/1000 BaseT)
- 2 x86 compatible CPUs
- 1 RJ-45 Serial (console) port
- 2 USB ports
- 1 dual-width AMC slot

The FortiGate-5001A-SW blade has:

- 2 network interfaces with a status LED for each network interface (2 10/100/1000 BaseT);
- 2 x86 compatible CPUs
- 1 RJ-45 Serial (console) port
- 2 USB ports
- 1 single-width AMC slot

The FortiGate-5001B blade has:

- 10 network interfaces with a status LED for each network interface (2 10/100/1000 BaseT, 8 10Gbit SFP+)
- 2 x86 compatible CPUs
- 1 RJ-45 Serial (console) port
- 2 USB ports
- The FortiGate-5001B blade includes a 64G SSD drive

AMC Module Descriptions

The FortiGate-5001A blades support one single or dual-width optional Advanced Mezzanine Card (AMC) components as described above. The AMC components can provide hard disk support or additional network interfaces. The validated configuration uses the following AMC modules:

- The ADM-FB8 dual width AMC networking module with 8 1Gbit SFP fiber ports, installed in the FortiGate-5001A-DW blade.
- The ASM-FB4 single width AMC networking module with 4 1Gbit SFP fiber ports., installed in the FortiGate-5001A-SW blade.

Cryptographic Module Ports and Interfaces

FortiGate-5001SX Blade

Figure 1: FortiGate-5001SX Front Panel




Table 2: FortiGate-5001SX Status LEDs

LED	State	Description	
PWR	Green	The Fortinet module is powered on.	
ACC	Off or Flashing red	The ACC LED flashes red when the Fortinet module accesses the FortiOS flash disk. The FortiOS flash disk stores the current FortiOS firmware build and configuration files. The system accesses the flash disk when starting up, during a firmware upgrade, or when an administrator is using the CLI or GUI to change the FortiOS configuration. Under normal operating conditions this LED flashes occasionally, but is mostly off.	
STA	Green	Normal operation.	
	Red	The Fortinet is starting or a fault condition exists.	
IPM	Blue	The Fortinet is ready to be hot-swapped (removed from the chassis). If the IPM light is blue and no other LEDs are lit the Fortinet module has lost power, possibly because of a loose or incorrectly aligned left extraction lever.	
	Flashing Blue	The Fortinet is changing from hot swap to running mode or from running mode to hot swap.	
	Off	Normal operation. The Fortinet module is in contact with the chassis backplane.	
1, 2, 3, 4	Green	The correct cable is connected to the gigabit SFP interface.	
	Flashing	Network activity at the gigabit SFP interface.	
5, 6, 7, 8	Link LED	Green	The correct cable is inserted into this interface and the connected equipment has power.
		Flashing	Network activity at this interface.
	Speed LED	Green	The interface is connected at 1000 Mbps.
		Amber	The interface is connected at 100 Mbps.
		Unlit	The interface is connected at 10 Mbps.

Table 3: FortiGate-5001SX Front Panel Connectors and Ports

Connector	Type	Speed	Supported Logical Interfaces	Description
1, 2, 3, 4	SFP	1Gbps	Data input, data output, control input and status output	Gigabit SFP interfaces that can accept fiber or copper gigabit transceivers. These interfaces only operate at 1000Mbps.
5, 6, 7, 8	RJ-45	10/100/1000 BaseT	Data input, data output, control input and status output	Copper gigabit connection to 10/100/1000Base-T copper networks.
Console Port	DB-9	9600 bps	Control input, status output	Optional connection to the management computer. Provides access to the command line interface (CLI).
USB Ports	USB	N/A	Key loading and archiving	Optional connection for FortiUSB token.

FortiGate-5001A-DW and SW Blades

Figure 2: FortiGate-5001A-DW Front Panel




Figure 3: FortiGate-5001A-SW Front Panel




Table 4: FortiGate-5001A-DW and SW Status LEDs

LED	State	Description
1,2 (Left LED)	Green	The correct cable is connected to the interface and the connected equipment has power.
	Flashing Green	Network activity at the interface.
	Off	No link is established.
1,2 (Right LED)	Green	Connection at 1 Gbps.
	Amber	Connection at 100 Mbps.
	Off	Connection at 10 Mbps.
Base CH0	Green	Base backplane interface 0(base1) is connected at 1 Gbps.
	Flashing Green	Network activity at base backplane interface 0.
Base CH1	Green	Base backplane interface 1 (base2) is connected at 1 Gbps.
	Flashing Green	Network activity at base backplane interface 1.
Fabric CH0	Green	Fabric backplane interface 0 (fabric1) is connected at 1 Gbps.
	Flashing Green	Network activity at fabric backplane interface 0.
Fabric CH1	Green	Fabric backplane interface 1 (fabric2) is connected at 1 Gbps.
	Flashing Green	Network activity at fabric backplane interface 1.
 ACC	Off or Flashing green	The ACC LED flashes green when the FortiGate-5001A blade accesses the FortiOS flash disk. The FortiOS flash disk stores the current FortiOS firmware build and configuration files. The system accesses the flash disk when starting up, during a firmware upgrade, or when an administrator is using the CLI or GUI to change the FortiOS configuration. Under normal operating conditions this LED flashes occasionally, but is mostly off.
 OOS	Off	Normal operation.
	Green	A fault condition exists and the FortiGate-5001A blade is out of service (OOS). This LED may also flash very briefly during normal startup.

 Power	Green	The FortiGate-5001A blade is powered on.
 Status	Green	The FortiGate-5001A blade is powered on.
 IPM	Blue	The FortiGate-5001A is ready to be hot-swapped (removed from the chassis). If the IPM light is blue and no other LEDs are lit the FortiGate-5001A blade has lost power.
	Flashing Blue	The FortiGate-5001A is changing from hot swap to running mode or from running mode to hot swap.
	Off	Normal operation. The FortiGate-5001A blade is in contact with the chassis backplane.

Table 5: FortiGate-5001A-DW Front Panel Connectors and Ports

Connector	Type	Speed	Supported Logical Interfaces	Description
1, 2	RJ-45	10/100/1000 Base T	Data input, data output, control input and status output	Copper gigabit connection to 10/100/1000Base-T copper networks.
CONSOLE	RJ-45	9600 bps	Control input, status output	Optional connection to the management computer. Provides access to the command line interface (CLI).
USB Ports	USB	N/A	Key loading and archiving	Optional connection for FortiUSB token.

FortiGate-5001B Blade

Figure 4: FortiGate-5001A-DW Front Panel




Table 6: FortiGate-5001B Status LEDs

LED	State	Description
1 to 8	Green	The correct cable is connected to the interface and the connected equipment has power.
	Flashing Green	Network activity at the interface.
	Off	No link is established.
Base 1	Green	Base backplane interface is connected at 1 Gbps.
	Flashing Green	Network activity at base backplane interface.
Base 2	Green	Base backplane interface is connected at 1 Gbps.
	Flashing Green	Network activity at base backplane interface.
Fabric 1	Green	Fabric backplane interface is connected at 10 Gbps.
	Flashing Green	Network activity at fabric backplane interface.
Fabric 2	Green	Fabric backplane interface is connected at 10 Gbps.
	Flashing Green	Network activity at fabric backplane interface.
 ACC	Off or Flashing green	The ACC LED flashes green when the FortiGate-5001B blade accesses the FortiOS flash disk. The FortiOS flash disk stores the current FortiOS firmware build and configuration files. The system accesses the flash disk when starting up, during a firmware upgrade, or when an administrator is using the CLI or GUI to change the FortiOS configuration. Under normal operating conditions this LED flashes occasionally, but is mostly off.
 OOS	Off	Normal operation.
	Green	A fault condition exists and the FortiGate-5001B blade is out of service (OOS). This LED may also flash very briefly during normal startup.
 Power	Green	The FortiGate-5001B blade is powered on.

 Status	Off	The FortiGate-5001B blade is powered on.
	Flashing	The FortiGate-5001B is starting up. If this LED is flashing at any time other than system startup, a fault condition may exist.
 IPM	Blue	The FortiGate-5001B is ready to be hot-swapped (removed from the chassis). If the IPM light is blue and no other LEDs are lit the FortiGate-5001A blade has lost power.
	Flashing	The FortiGate-5001B is changing from hot swap to running mode or from running mode to hot swap.
	Off	Normal operation. The FortiGate-5001B blade is in contact with the chassis backplane.

Table 7: FortiGate-5001B Front Panel Connectors and Ports

Connector	Type	Speed	Supported Logical Interfaces	Description
1 to 8	SFP+	10Gbps	Data input, data output, control input and status output	
MGMT1 and MGMT 2	RJ-45	10/100/1000 Base-T	Data input, data output, control input and status output	
CONSOLE	RJ-45	9600 bps	Control input, status output	Optional connection to the management computer. Provides access to the command line interface (CLI).
USB Port	USB	N/A		Optional connection for USB token.

ADM-FB8 AMC Component

Figure 5: ADM-FB8 AMC Component




Table 8: ADM-FB8 Status LEDs

LED	State	Description
HS	Blue	Ejection latch open.
	Flashing Blue	Ejection latch opened during system operation.
OOS		Reserved for future use.
PWR	Amber	The module is properly inserted in the FortiGate unit.
	Off	The module is not receiving power from the FortiGate unit.
OT		Reserved for future use
LINK	Green	The correct cable is in use and the connected equipment has power.
	Off	No link established.
ACT	Flashing Amber	Network activity at this interface.
	Off	No network activity at this interface.

Table 9: ADM-FB8 Front Panel Connectors and Ports

Connector	Type	Speed	Supported Logical Interfaces	Description
1-8	LC-SFP	1Gbps	Data input, data output, control input and status output	Accelerated gigabit SFP interfaces that can accept fiber or copper gigabit transceivers.

ASM-FB4 AMC Component

Figure 6: ASM-FB4 AMC Component




Table 10: ASM-FB4 Status LEDs

LED	State	Description
HS	Blue	Ejection latch open.
	Flashing Blue	Ejection latch opened during system operation.
OOS		Reserved for future use.
PWR	Amber	The module is properly inserted in the FortiGate unit.
	Off	The module is not receiving power from the FortiGate unit.

Table 10: ASM-FB4 Status LEDs

LED	State	Description
OT		Reserved for future use.
LINK	Green	The correct cable is in use and the connected equipment has power.
	Off	No link established.
ACT	Flashing Amber	Network activity at this interface.
	Off	No network activity as this interface.

Table 11: ASM-FB4 Front Panel Connectors and Ports

Connector	Type	Speed	Supported Logical Interfaces	Description
Ports 1 to 4	SERDES compatible SX fiber	1000 BaseSX	Data input, data output, control input and status output	Fiber network connections.

FortiGate-5140 Chassis

Figure 7: FortiGate-5140 Front Panel





Figure 8: FortiGate-5140 Rear Panel



Web-Based Manager

The FortiGate web-based manager provides GUI based access to the module and is the primary tool for configuring the module. The manager requires a web browser on the management computer and an Ethernet connection between the FortiGate unit and the management computer.

A web-browser that supports Transport Layer Security (TLS) 1.0 is required for remote access to the web-based manager when the module is operating in FIPS-CC mode. HTTP access to the web-based manager is not allowed in FIPS-CC mode and is disabled.

Figure 9: The FortiGate web-based manager

The screenshot displays the FortiGate web-based manager interface for configuring a new Phase 1 IPsec proposal. The left sidebar shows the navigation menu with 'VPN' selected. The main content area is titled 'New Phase 1' and contains the following configuration fields:

- Name:** (empty text field)
- Remote Gateway:** Static IP Address (dropdown)
- IP Address:** 0.0.0.0 (text field)
- Local Interface:** wan1 (dropdown)
- Mode:** Aggressive (radio), Main (ID protection) (radio, selected)
- Authentication Method:** Pre-shared Key (dropdown)
- Pre-shared Key:** (empty text field)
- Peer Options:**
 - Accept any peer ID (radio, selected)
 - (XAUTH, NAT Traversal, DPI) (text)
- Advanced...** (button)
- Enable IPsec Interface Mode:** (checkbox, unchecked)
- Local Gateway IP:** Main Interface IP (radio, selected), Specify (radio, unchecked)
- DNS Server:** Use System DNS (radio, selected), Specify (radio, unchecked)
- P1 Proposal:**
 - Encryption: 3DES (dropdown), Authentication: SHA1 (dropdown)
 - 2 - 1 encryption: AES-128 (dropdown), Authentication: SHA1 (dropdown)
- DH Group:** 2 (checkbox, unchecked), 5 (checkbox, checked), 14 (checkbox, unchecked)
- Keylife:** 28800 (text field), (120-172800 seconds) (text)
- Local ID:** (text field), (optional) (text)
- XAUTH:** Disable (radio, selected), Enable as Client (radio, unchecked), Enable as Server (radio, unchecked)
- NAT Traversal:** Enable (checkbox, checked)
- Keepalive Frequency:** 10 (text field), (10-4000 seconds) (text)
- Dead Peer Detection:** Enable (checkbox, checked)

At the bottom of the configuration area are 'OK' and 'Cancel' buttons.

Command Line Interface

The FortiGate Command Line Interface (CLI) is a full-featured, text based management tool for the module. The CLI provides access to all of the possible services and configuration options in the module. The CLI uses a console connection or a network (Ethernet) connection between the FortiGate unit and the management computer. The console connection is a direct serial connection. Terminal emulation software is required on the management computer using either method. For network access, a Telnet or SSH client that supports the SSH v2.0 protocol is required (SSH v1.0 is not supported in FIPS-CC mode). Telnet access to the CLI is not allowed in FIPS-CC mode and is disabled.

Roles, Services and Authentication

Roles

When configured in FIPS-CC mode, the module provides the following roles:

- Crypto Officer
- Network User

The Crypto Officer role is initially assigned to the default 'admin' operator account. The Crypto Officer role has read-write access to all of the module's administrative services. The initial Crypto Officer can create additional operator accounts. These additional accounts are assigned the Crypto Officer role and can be assigned a range of read/write or read only access permissions including the ability to create operator accounts.

The module provides a **Network User** role for end-users (Users). Network users can make use of the encrypt/decrypt services, but cannot access the module for administrative purposes.

The module does not provide a Maintenance role.

FIPS Approved Services

The following tables detail the types of FIPS approved services available to each role, the types of access for each role and the Keys or CSPs they affect.

The role names are abbreviated as follows:

Crypto Officer CO
User U

The access types are abbreviated as follows:

Read Access R
Write Access W
Execute Access E

Table 12: Services available to Crypto Officers

Service	Access	Key/CSP
authenticate to module	WE	Operator Password, Diffie-Hellman Key, HTTP/TLS and SSH Server/Host Keys, HTTPS/TLS and SSH Session Authentication Keys, and HTTPS/TLS Session Encryption Keys, RNG Seed, RNG AES Key
show system status	WE	N/A
show FIPS-CC mode enabled/disabled (console/CLI only)	WE	N/A
enable FIPS-CC mode of operation (console only)	WE	Configuration Integrity Key
execute factory reset (zeroize keys, disable FIPS mode, console/CLI only)	E	See " Key Zeroization " on page 20
execute FIPS-CC on-demand self-tests (console only)	E	Configuration Integrity Key, Firmware Integrity Key
add/delete operators and network users	WE	Operator Password, Network User Password
set/reset operator and network user passwords	WE	Operator Password, Network User Password
backup configuration file	WE	Configuration Encryption Key, Configuration Backup Key
read/set/delete/modify module configuration	WE	N/A
enable/disable alternating bypass mode	WE	N/A

Table 12: Services available to Crypto Officers

Service	Access	Key/CSP
read/set/delete/modify IPSec/SSL VPN configuration	N/A	IPSec: IPSec Manual Authentication Key, IPSec Manual Encryption Key, IKE Pre-Shared Key, IKE RSA Key SSL: HTTPS/TLS Server/Host Key, HTTPS/TLS Session Authentication Key, HTTPS/TLS SSH Session Encryption Key
read/set/delete/modify HA configuration	WE	HA Password, HA Encryption Key
execute firmware update	E	Firmware Update Key
read log data	WE	N/A
delete log data (console/CLI only)	N/A	N/A
execute system diagnostics (console/CLI only)	WE	N/A

Table 13: Services available to Network Users

Service/CSP	Access	Key/CSP
authenticate to module	E	Network User Password, Diffie-Hellman Key, HTTPS/TLS Server/Host Key, HTTPS/TLS Session Authentication Key, HTTPS/TLS Session Encryption Key, RNG Seed, RNG AES Key
IPSec VPN controlled by firewall policies	E	Diffie-Hellman Key, IKE and IPSec Keys, RNG Seed, RNG AES Key
SSL VPN controlled by firewall policies	E	Network User Password, Diffie-Hellman Key, HTTPS/TLS Server/Host Key, HTTPS/TLS Session Authentication Key, HTTPS/TLS Session Encryption Key, RNG Seed, RNG AES Key

Authentication

The modules implement identity based authentication. Operators must authenticate with a user-id and password combination to access the modules remotely or locally via the console. Remote operator authentication is done over HTTPS (TLS) or SSH. Password entry is obfuscated using asterisks and the module does not provide feedback on the authentication process - i.e. the module does not indicate if the password or the user/operator account is incorrect for a failed authentication attempt.

By default, Network User access to the modules is based on firewall policy and authentication by IP address or fully qualified domain names. Network Users can optionally be forced to authenticate to the modules using a username/password combination to enable use of the IPSec VPN encrypt/decrypt or bypass services. For Network Users invoking the SSL-VPN encrypt/decrypt services, the modules support authentication with a user-id/password combination. Network User authentication is done over HTTPS and does not allow access to the modules for administrative purposes.

Note that operator authentication over HTTPS/SSH and Network User authentication over HTTPS are subject to a limit of 3 failed authentication attempts in 1 minute. Operator authentication using the console is not subject to a failed authentication limit, but the number of authentication attempts per minute is limited by the bandwidth available over the serial connection.

The minimum password length is 8 characters when in FIPS-CC mode (maximum password length is 32 characters). Using a strong password policy, where operator and network user passwords are at least 8 characters in length and use a mix of alphanumeric (printable) characters from the ASCII character set (as explained in [“FIPS 140-2 Compliant Operation” on page 24](#)), the odds of guessing a password are 1 in $8! \times 26 \times 10 \times 32 \times 94^5$.

For Network Users invoking the IPSec VPN encrypt/decrypt services, the module acts on behalf of the Network User and negotiates a VPN connection with a remote module. The strength of authentication for IPSec services is based on the authentication method defined in the specific firewall policy: IPSec manual authentication key, IKE pre-shared key or IKE RSA key (RSA certificate). The odds of guessing the authentication key for each IPSec method is:

- 1 in 16^{40} for the IPSec Manual Authentication key (based on a 40 digit, hexadecimal key)
- 1 in 94^8 for the IKE Pre-shared Key (based on an 8 character, ASCII printable key)
- 1 in 2^{1024} for the IKE RSA Key (based on a 1024bit RSA key size)

Therefore the minimum odds of guessing the authentication key for IPSec is 1 in 94^8 , based on the IKE Pre-shared key.

Physical Security

The modules meet FIPS 140-2 Security Level 2 requirements by using production grade components and an opaque, sealed enclosure. Access to the enclosure is restricted through the use of tamper-evident seals to secure the overall enclosure.

The seals are serialized red wax/plastic with black lettering that reads “Fortinet Security Seal”.

The tamper seals are not applied at the factory prior to shipping. It is the responsibility of the Crypto Officer to apply the seals before use to ensure full FIPS 140-2 compliance. The seals must be installed for the module to operate in a FIPS Approved mode of operation. Once the seals have been applied, the Crypto Officer must develop an inspection schedule to verify that the external enclosure of the module and the tamper seals have not been damaged or tampered with in any way. The Crypto Officer is also responsible for securing and controlling any unused seals.

The surfaces should be cleaned with rubbing alcohol to remove dirt and oil before applying the seals. Ensure the surface is completely clean and dry before applying the seals. If a seal needs to be re-applied, completely remove the old seal and clean the surface with an adhesive remover before following the instructions for applying a new seal.

Additional seals can be ordered through your Fortinet sales contact. Reference the following SKU when ordering: FIPS-SEAL-RED. Specify the number of seals required based on the specific module as described below.

The FortiGate-5140 uses 23 seals to secure:

- the blades, shelf-manager, shelf-alarm and blank face plates (10 seals, see [Figure 10](#))
- the rear panel blank face plates (13 seals, see [Figure 11](#))

Figure 10: FortiGate-5140 front seals





Figure 11: FortiGate-5140 rear panel seals



Operational Environment

This section is not applicable to the modules. The modules utilize a firmware based, proprietary and non-modifiable operating system that does not provide a programming environment.

Cryptographic Key Management

Random Number Generation

The modules use a firmware based, deterministic random number generator that conforms to ANSI X9.31 Appendix A.2.4.

Key Zeroization

The following keys are zeroized by executing a factory reset followed by a firmware update.

- ANSI X9.31 RNG AES Key
- Firmware Update Key
- Firmware Integrity Key
- Configuration Integrity Key
- Configuration Backup Key
- SSH Server/Host Key
- HTTPS/TLS Server/Host Key

All other keys and CSPs are zeroized when the operator executes a factory reset or when enabling or disabling the FIPS-CC mode of operation.

See [Table 16 on page 21](#) for a complete list of keys and CSPs.

Algorithms

Table 14: FIPS Approved or Allowed Algorithms

Algorithm	NIST Certificate Number
RNG (ANSI X9.31 Appendix A)	996
Triple-DES	958, 961, 1205, 1234, 1235
AES	1405, 1408, 1858, 1899, 1900
SHA-1	1275, 1278, 1635, 1668, 1669
HMAC SHA-1	826, 829, 1105, 1139, 1140
RSA ANSI X9.31 (key generation, signature generation and verification)	685, 973
RSA PKCS1 (digital signature creation and verification)	685, 973

Table 15: Non-FIPS Approved Algorithms

Algorithm
DES (disabled in FIPS-CC mode)
MD5 (disabled in FIPS-CC mode except for use in the TLS protocol)
HMAC MD5 (disabled in FIPS-CC mode)
Diffie-Hellman (key agreement; key establishment methodology provides between 96 and 196 bits of encryption strength)
RSA (key wrapping; key establishment methodology provides 80 or 112 bits of encryption strength)
SHA-256 (non-compliant)
HMAC SHA-256 (non-compliant)

Note that some algorithms may be classified as deprecated, restricted, or legacy-use. Please consult NIST SP 800-131A for details.

Cryptographic Keys and Critical Security Parameters

The following table lists all of the cryptographic keys and critical security parameters used by the module. The following definitions apply to the table:

Key or CSP	The key or CSP description.
Storage	Where and how the keys are stored
Usage	How the keys are used

Table 16: Cryptographic Keys and Critical Parameters used in FIPS-CC Mode

Key or CSP	Storage	Usage
Diffie-Hellman Keys	SDRAM Plaintext	Key agreement and key establishment
IPSec Manual Authentication Key	Flash RAM AES encrypted	Used as IPSec Session Authentication Key
IPSec Manual Encryption Key	Flash RAM AES encrypted	Used as IPSec Session Encryption Key

Table 16: Cryptographic Keys and Critical Parameters used in FIPS-CC Mode

Key or CSP	Storage	Usage
IPSec Session Authentication Key	SDRAM Plain-text	IPSec peer-to-peer authentication using HMAC SHA-1
IPSec Session Encryption Key	SDRAM Plain-text	VPN traffic encryption/decryption using Triple-DES or AES
IKE Pre-Shared Key	Flash RAM AES encrypted	Used to generate IKE protocol keys
IKE Authentication Key	SDRAM Plain-text	IKE peer-to-peer authentication using HMAC SHA-1 (SKEYID_A)
IKE Key Generation Key	SDRAM Plain-text	IPSec SA keying material (SKEYID_D)
IKE Session Encryption Key	SDRAM Plain-text	Encryption of IKE peer-to-peer key negotiation using Triple-DES or AES (SKEYID_E)
IKE RSA Key	Flash Ram Plain text	Used to generate IKE protocol keys
RNG Seed (ANSI X9.31 Appendix A.2.4)	Flash RAM Plain-text	Seed used for initializing the RNG
RNG AES Key (ANSI X9.31 Appendix A.2.4)	Flash RAM Plain-text	AES Seed key used with the RNG
Firmware Update Key	Flash RAM Plain-text	Verification of firmware integrity when updating to new firmware versions using RSA public key
Firmware Integrity Key	Flash RAM Plain-text	Verification of firmware integrity in the firmware integrity test using RSA public key
HTTPS/TLS Server/Host Key	Flash RAM Plain-text	RSA private key used in the HTTPS/TLS protocols
HTTPS/TLS Session Authentication Key	SDRAM Plain-text	HMAC SHA-1 key used for HTTPS/TLS session authentication
HTTPS/TLS Session Encryption Key	SDRAM Plain-text	AES or Triple-DES key used for HTTPS/TLS session encryption
SSH Server/Host Key	Flash RAM Plain-text	RSA private key used in the SSH protocol
SSH Session Authentication Key	SDRAM Plain-text	HMAC SHA-1 key used for SSH session authentication
SSH Session Encryption Key	SDRAM Plain-text	AES or Triple-DES key used for SSH session encryption
Operator Password	Flash RAM SHA-1 hash	Used to authenticate operator access to the module
Configuration Integrity Key	Flash RAM Plain-text	SHA-1 hash used for configuration/VPN bypass test
Configuration Encryption Key	Flash RAM Plain-text	AES key used to encrypt CSPs on the flash RAM and in the backup configuration file (except for operator passwords in the backup configuration file)
Configuration Backup Key	Flash RAM Plain-text	HMAC SHA-1 key used to encrypt operator passwords in the backup configuration file

Table 16: Cryptographic Keys and Critical Parameters used in FIPS-CC Mode

Key or CSP	Storage	Usage
Network User Password	Flash RAM AES encrypted	Used during network user authentication
HA Password	Flash RAM AES encrypted	Used to authenticate FortiGate units in an HA cluster
HA Encryption Key	Flash RAM AES encrypted	Encryption of traffic between units in an HA cluster using AES

Alternating Bypass Feature

The primary cryptographic function of the module is as a firewall and VPN device. The module implements two forms of alternating bypass for VPN traffic: policy based (for IPSec and SSL VPN) and interface based (for IPSec VPN only).

Policy Based VPN

Firewall policies with an action of IPSec or SSL-VPN mean that the firewall is functioning as a VPN start/end point for the specified source/destination addresses and will encrypt/decrypt traffic according to the policy. Firewall policies with an action of allow mean that the firewall is accepting/sending plaintext data for the specified source/destination addresses.

A firewall policy with an action of accept means that the module is operating in a bypass state for that policy. A firewall policy with an action of IPSec or SSL-VPN means that the module is operating in a non-bypass state for that policy.

Interface Based VPN

Interface based VPN is supported for IPSec only. A virtual interface is created and any traffic routed to the virtual interface is encrypted and sent to the VPN peer. Traffic received from the peer is decrypted. Traffic through the virtual interface is controlled using firewall policies. However, unlike policy based VPN, the action is restricted to Accept or Deny and all traffic controlled by the policy is encrypted/decrypted.

When traffic is routed over the non-virtual interfaced, the module is operating in a bypass state. When traffic is routed over the virtual interface, the module is operating in a non-bypass state.

In both cases, two independent actions must be taken by a CO to create bypass firewall policies: the CO must create the bypass policy and then specifically enable that policy.

Key Archiving

The module supports key archiving to a management computer or USB token as part of a module configuration file backup. Operator entered keys are archived as part of the module configuration file. The configuration file is stored in plain text, but keys in the configuration file are either AES encrypted using the Configuration Encryption Key or stored as a keyed hash using HMAC-SHA-1 using the Configuration Backup Key.

Electromagnetic Interference/Electromagnetic Compatibility (EMI/EMC)

The modules comply with EMI/EMC requirements for Class A (business use) devices as specified by Part 15, Subpart B, of the FCC rules. The following table lists the specific lab and FCC report information for the modules.

Table 17: FCC Report Information

Module	Lab Information	FCC Report Number
FG-5001SX	Compliance Certification Services Inc. 561F Monterey Road Morgan Hill, CA, 95037, USA (408) 463-0885	06U10772-1
FG-5001A-DW and SW	Bay Area Compliance Laboratories Corp. 1274 Anvilwood Ave. Sunnyvale, CA 94089 (408) 732-9162	R0805134
FG-5001B	Declaration of Conformance	N/A

Mitigation of Other Attacks

The module includes a real-time Intrusion Prevention System (IPS) as well as antivirus protection, antispam and content filtering. Use of these capabilities is optional.

The FortiOS IPS has two components: a signature based component for detecting attacks passing through the FortiGate appliance and a local attack detection component that protects the firewall from direct attacks. Functionally, signatures are similar to virus definitions, with each signature designed to detect a particular type of attack. The IPS signatures are updated through the FortiGuard IPS service. The IPS engine can also be updated through the FortiGuard IPS service.

FortiOS antivirus protection removes and optionally quarantines files infected by viruses from web (HTTP), file transfer (FTP), and email (POP3, IMAP, and SMTP) content as it passes through the FortiGate modules. FortiOS antivirus protection also controls the blocking of oversized files and supports blocking by file extension. Virus signatures are updated through the FortiGuard antivirus service. The antivirus engine can also be updated through the FortiGuard antivirus service.

FortiOS antispam protection tags (SMTP, IMAP, POP3) or discards (SMTP only) email messages determined to be spam. Multiple spam detection methods are supported including the FortiGuard managed antispam service.

FortiOS web filtering can be configured to provide web (HTTP) content filtering. FortiOS web filtering uses methods such as banned words, address block/exempt lists, and the FortiGuard managed content service.

Whenever a IPS, antivirus, antispam or filtering event occurs, the modules can record the event in the log and/or send an alert email to an operator.

For complete information refer to the FortiGate Installation Guide for the specific module in question, the FortiGate Administration Guide and the FortiGate IPS Guide.

FIPS 140-2 Compliant Operation

FIPS 140-2 compliant operation requires both that you use the module in its FIPS-CC mode of operation and that you follow secure procedures for installation and operation of the FortiGate unit. You must ensure that:

- The FortiGate unit is configured in the FIPS-CC mode of operation.

- The FortiGate unit is installed in a secure physical location.
- Physical access to the FortiGate unit is restricted to authorized operators.
- Administrative passwords are at least 8 characters long.
- Administrative passwords are changed regularly.
- Administrator account passwords must have the following characteristics:
 - One (or more) of the characters should be capitalized
 - One (or more) of the characters should be numeric
 - One (or more) of the characters should be non alpha-numeric (e.g. punctuation mark)
- Administration of the module is permitted using only validated administrative methods. These are:
 - Console connection
 - Web-based manager via HTTPS
 - Command line interface (CLI) access via SSH
- Diffie-Hellman groups of less than less than 1024 bits (Group 5) are not used.
- Client side RSA certificates must use 1024 bit or greater key sizes.
- LDAP based authentication must use secure LDAP (LDAPS).
- Only approved algorithms are used (see [Table 14 on page 21](#)).

The module can be used in either of its two operation modes: NAT/Route or Transparent. NAT/Route mode applies security features between two or more different networks (for example, between a private network and the Internet). Transparent mode applies security features at any point in a network. The current operation mode is displayed on the web-based manager Status page and in the output of the `get system status` CLI command. Also, on LCD-equipped modules, Transparent mode is indicated by “FIPS-CC-TP” and NAT/Route by “FIPS-CC-NAT” on the LCD display.

Enabling FIPS-CC mode

To enable the FIPS 140-2 compliant mode of operation, the operator must execute the following command from the Local Console:

```
config system fips
  set status enable
```

The Operator is required to supply a password for the admin account which will be assigned to the Crypto Officer role.

The supplied password must be at least 8 characters long and correctly verified before the system will restart in FIPS-CC mode.

Upon restart, the module will execute self-tests to ensure the correct initialization of the module’s cryptographic functions.

After restarting, the Crypto Officer can confirm that the module is running in FIPS-CC mode by executing the following command from the CLI:

```
get system status
```

If the module is running in FIPS-CC mode, the system status output will display the line:

```
FIPS-CC mode: enable
```

Note that enabling/disabling the FIPS-CC mode of operation will automatically invoke the key zeroization service. The key zeroization is performed immediately after FIPS-CC mode is enabled/disabled.

Self-Tests

The module executes the following self-tests during startup and initialization:

- Firmware integrity test using RSA signatures
- Configuration/VPN bypass test using HMAC SHA-1
- Triple-DES, CBC mode, encrypt/decrypt known answer test
- AES, CBC mode, encrypt/decrypt known answer test
- HMAC SHA-1 known answer test
- SHA-1 known answer test (tested as part of HMAC SHA-1 known answer test)
- RSA signature generation/verification known answer test
- RNG known answer test

The results of the startup self-tests are displayed on the console during the startup process. The startup self-tests can also be initiated on demand using the CLI command **execute fips kat all** (to initiate all self-tests) or **execute fips kat <test>** (to initiate a specific self-test).

The module executes the following conditional tests when the related service is invoked:

- Continuous RNG test
- RSA pairwise consistency test
- Configuration/VPN bypass test using HMAC SHA-1
- Firmware load test using RSA signatures

If any of the self-tests or conditional tests fail, the module enters an error state as shown by the console output below:

```
Self-tests failed
Entering error mode...
The system is going down NOW !!
The system is halted.
```

All data output and cryptographic services are inhibited in the error state.

Non-FIPS Approved Services

The module also provides the following non-FIPS approved services:

- Encrypted configuration backups using the backup configuration password
- LLTP and PPTP VPN

If the above services are used, the module is not considered to be operating in the FIPS approved mode of operation.