

Palo Alto Networks, Inc. WildFire 9.0 WF-500

FIPS 140-2 Non-Proprietary Security Policy

Version: 1.1

Revision Date: June 29, 2022

Palo Alto Networks, Inc. www.paloaltonetworks.com

© 2022 Palo Alto Networks, Inc. Palo Alto Networks, Inc. is a registered trademark of Palo Alto Networks, Inc. A list of our trademarks can be found at https://www.paloaltonetworks.com/company/trademarks.html. All other marks mentioned herein may be trademarks of their respective companies.

This document may be freely reproduced and distributed whole and intact including this copyright notice.

Table of Contents

1.	Module Overview	3
2.	Security Levels	4
3.	Modes of Operation	4
4.	Ports and Interfaces	9
5.	Roles, Services, and Authentication	11
6.	Operational Environment	15
7.	Self-Tests / Security Rules	15
8.	Physical Security	17
9.	Mitigation of Other Attacks	18
10.	References	18
11.	Definitions and Acronyms	18
App	endix - WF-500 FIPS Kit Installation Guide (12 Tamper-Evident Seals)	19

1. Module Overview

The WildFire 9.0 WF-500 module identifies unknown malware, zero-day exploits, and Advanced Persistent Threats (APTs) through dynamic analysis, and automatically disseminates protection in near real-time to help security teams meet the challenge of advanced cyber-attacks.

Unknown files are analyzed by WildFire in a scalable sandbox environment where new threats are identified, and protections are automatically developed and delivered in the form of an update. The result is a unique, closed loop approach to controlling cyber threats that begins with positive security controls to reduce the attack surface, inspection of all traffic, ports, and protocols to block all known threats, and rapid detection of unknown threats by observing their actual behavior.

The Palo Alto Networks, Inc. WildFire 9.0 WF-500 is a multi-chip standalone module. The module is shown in Figure 1. The module boundary is the outer chassis enclosure. The cryptographic boundary includes all the logical components of the modules and the physical boundary is the outer perimeter of the enclosure of the WF-500. **Error! Reference source not found.** through **Error! Reference source not found.** provide images of the module with the FIPS kit's opacity shields in place. See the Physical Security section for details regarding the module's physical security mechanisms.

ModulePart NumberHardware
VersionFIPS Kit Part NumberFIPS Kit Hardware
VersionFirmware
VersionWF-500910-00009700G920-00014500A9.0.9-h1

Table 1 - Validated Version Information



Figure 1 - Front view of WF-500



Figure 2 - Front view of WF-500 with opacity shield



Figure 3 - Rear view of WF-500 with opacity shield



Figure 4 - Right side of WF-500 with opacity shields



Figure 5 - Left side of WF-500 with opacity shields

2. Security Levels

The cryptographic module meets the overall requirements applicable to Level 2 security of FIPS 140-2.

Table 2 - Module Security Level Specification

Security Requirements Section	Level
Cryptographic Module Specification	2
Module Ports and Interfaces	2
Roles, Services, Authentication	3
Finite State Model	2
Physical Security	2
Operational Environment	N/A
Cryptographic Key Management	2
EMI/EMC	2
Self-Tests	2
Design Assurance	3
Mitigation of Other Attacks	N/A

3. Modes of Operation

The module provides both a FIPS 140-2 Approved and a non-Approved mode of operation. This module is configured during initialization to operate only in an Approved or non-Approved mode of operation when in the operational state. The module cannot alternate service by service between Approved and non-Approved modes of operation.

Approved Mode of Operation

The following procedure will place the module into the Approved mode of operation:

- Install module and interface connections in addition to the FIPS kit.
- The tamper-evident seals and opacity shields must be installed as per Appendix A for the module to operate in the FIPS Approved mode of operation.
- Apply power to the device.
- Establish a serial connection to the console port and command the module to enter into maintenance mode.

- Enter the command: "debug system maintenance-mode".
- Type 'Y' to continue and reboot.
- The module will reboot, and then enter maintenance mode.
- After reboot, select "Continue."
- Select the "Set FIPS-CC" option, and press enter.
- Select "Enable FIPS-CC Mode," and press enter.
- When prompted, select "Reboot" and the module will re-initialize and continue into the Approved mode.
- The module will reboot.
- In the Approved mode, the console port is available only as a status output port.

The module will automatically indicate the Approved mode of operation in the following manner:

- Status output interface will indicate "**** FIPS-CC MODE ENABLED ****" via the CLI session.
- Status output interface will indicate "FIPS-CC mode enabled successfully" via the console port.

Should one or more power-up self-tests fail, the module will not enter the FIPS Approved mode of operation. Feedback will consist of:

- The module will output "FIPS-CC failure."
- The module will reboot and enter a state in which the reason for the reboot can be determined by following the on-screen instructions.

Non-Approved Mode of Operation

The following procedure will put the module into the non-Approved mode of operation:

- Access the module's CLI via SSH, and command the module to enter maintenance mode; the module will reboot
 - Note: Establish a serial connection to the console port
- After reboot, select "Continue."
- Select the "Set FIPS-CC" option, and press enter.
- Select "Disable FIPS-CC Mode," and press enter.
- The module will disable FIPS-CC mode, and perform a factory reset (zeroization)
- Once complete, the module will provide the following status output:
 - "Set FIPS-CC Mode Status: Success"

The following procedure will zeroize the module:

- Access the module's CLI via SSH, and command the module to enter maintenance mode; the module will reboot
 - o Note: Establish a serial connection to the console port
- After reboot, select "Continue."
- Select "Factory Reset."
- The module will perform a zeroization, and provide the following message once complete:
 - "Factory Reset Status: Success"

Approved and Allowed Algorithms

The cryptographic module has the following CAVP certificates:

Table 3 - CAVP Certificates for FIPS Approved Algorithms

FIPS Approved Algorithm	CAVP Cert. #
AES [FIPS 197, SP800-38A]: Functions: Encryption, Decryption ECB, CBC, CTR modes; Encrypt/Decrypt; 128, 192 and 256-bit CFB128 mode; Encrypt/Decrypt; 128-bit Note: AES-OFB (128, 192, 256 bit), AES-CFB1 (128, 192, 256 bit), AES-CFB8 (128, 192, 256 bit), and AES-CFB128 (192, 256 bit) were also tested but are not available for use.	C1005
AES-CCM [SP800-38C]: Encrypt and Decrypt, 128-bit Note: AES-CCM was tested but is not used by the module except for the self-test.	C1005
AES-GCM [SP800-38D]: Encrypt and Decrypt, 128 and 256-bit Functions: Authenticated Encryption, Authenticated Decryption Note 1: GCM IV handling is compliant with FIPS IG A.5 and SP800-38D.* Note 2: GCM 192-bit was tested but is not used by the module. Note 3: AES-GMAC was tested but is not available for use.	C1005
CKG [SP800-133]: Function: Key Generation Method 1: Asymmetric Key Generation; SP800-133 §6, seed results from an unmodified DRBG output Method 2: Symmetric Key Generation; SP800-133 §7.1 (symmetric key results from an unmodified DRBG output), §7.2, and §7.3	Vendor Affirmed
CVL: ECDSA Signature Generation P-256 SHA: SHA-224, SHA-256, SHA-384, SHA-512 P-384 SHA: SHA-224, SHA-256, SHA-384, SHA-512 P-521 SHA: SHA-224, SHA-256, SHA-384, SHA-512 Note: P-256, P-384 and P-521 were tested, but are not used by the module.	C1005
CVL: KDF, Application Specific [SP800-135] -TLSv1.0/1.1/1.2 KDF -SNMPv3 KDF -SSHv2 KDF -IKEv1/v2 KDF Note: IKEv1 KDFs were tested but are not used by the module.	C1005
CVL: RSA [SP800-56B] Functions: Key Unwrap -RSADP Note: Tested but not used.	C1005
DRBG [SP800-90A] -CTR DRBG with AES-256 Derivation function enabled	C1005
DSA [FIPS 186-4] -Key Generation: 2048 bits	C1005
ECDSA [FIPS 186-4] -Key Pair Generation: P-256, P-384, P-521 -Public Key Validation: P-256, P-384, P-521 -Signature Generation: P-256, P-384, and P-521 with hashes	C1005

(SHA-256/384/512) -Signature Verification: P-224, P-256, P-384, and P-521 with hashes (SHA-1/224/256/384/512)	
HMAC [FIPS 198] - HMAC-SHA-1 with λ =96, 160 - HMAC-SHA-256 with λ =256 - HMAC-SHA-384 with λ =384 - HMAC-SHA-512 with λ =512	C1005
KAS-SSC: SP 800-56A Rev.3 Elliptic Curve Diffie-Hellman Exchange (key agreement; key establishment methodology provides between 128 and 256 bits of encryption strength) and Diffie-Hellman Exchange (key agreement; key establishment methodology provides 112 bits of encryption strength)	A2670
KAS (KAS-SSC Cert. #A2670, CVL Cert. #C1005): SP 800-56A Rev3 compliant key agreement scheme, where testing was performed separately for the shared secret computation and for a TLS, SSH, and IKE KDF compliant with SP 800-135 Rev1	KAS-SSC Cert. A2670 CVL Cert. C1005
KTS [SP800-38F §3.1]: AES-GCM (Key wrapping; key establishment methodology provides 128 bit or 256 bits of encryption strength)	C1005
KTS [SP800-38F §3.1]: AES-CBC (128/192/256 bits) plus HMAC AES-CTR (128/192/256 bits) plus HMAC (Key wrapping; key establishment methodology provides between 128 bit and 256 bits of encryption strength)	C1005
RSA [FIPS 186-4] - Key Pair Generation: 2048 and 3072 - Signature Generation (ANSI X9.31, RSASSA-PKCS1_v1-5, RSASSA-PSS): 2048, 3072, and 4096-bit with hashes (SHA-1+/256/384/512) - Signature Verification (ANSI X9.31, RSASSA-PKCS1_v1-5, RSASSA-PSS): 1024++, 2048, 3072, 4096-bit (per IG A.14) with hashes (SHA-1/224+++/256/384/512) +: Only used for signature generation in SSH in the Approved Mode; Mod 4096 does not support SHA-1 +	C1005
Safe Primes Key Generation and Verification using MODP-2048	A2670
SHA-1, SHA-256, SHA-384, SHA-512 [FIPS 180-4] Functions: Digital Signature Generation, Digital Signature Verification, non-Digital Signature Applications	C1005
(Note: SHA-224 was tested, but is not used by the module) *The module is compliant to IC A 5: CCM is used in the context of TLS. IDsec/IVEv2	

^{*}The module is compliant to IG A.5: GCM is used in the context of TLS, IPsec/IKEv2, and SSH:

• For TLS, The GCM implementation meets Scenario 1 of IG A.5: it is used in a manner compliant with SP 800-52 and in accordance with Section 4 of RFC 5288 for TLS key establishment, and ensures when the nonce_explicit part of the IV exhausts all possible values for a given session key, that a new TLS handshake is initiated per sections 7.4.1.1 and 7.4.1.2 of RFC 5246. (From this RFC 5288, the GCM cipher suites in use are TLS_RSA_WITH_AES_128_GCM_SHA256, TLS_RSA_WITH_AES_256_GCM_SHA384, TLS_ECDHE_ECDSA_WITH_AES_128_GCM_SHA256, TLS_ECDHE_ECDSA_WITH_AES_256_GCM_SHA384,

TLS_ECDHE_RSA_WITH_AES_128_GCM_SHA256, and TLS_ECDHE_RSA_WITH_AES_256_GCM_SHA384.) During operational testing, the module was tested against an independent version of TLS and found to behave correctly.

- For IPsec/IKEv2, The GCM implementation meets Scenario 1 of IG A.5: it is used in a manner compliant with RFCs 4106 and 7296 (RFC 5282 is not applicable, as the module does not use GCM within IKEv2 itself), and ensures when the module exhausts all possible values for a given session key that this triggers a rekey condition. During operational testing, the module was tested against an independent version of IPsec with IKEv2 and found to behave correctly.
- For SSH, the module meets Scenario 4 of IG A.5. The fixed field is 32 bits in length and is derived using the SSH KDF; this ensures the fixed field is unique for any given GCM session. The invocation field is 64 bits in length and is incremented for each invocation of GCM; this prevents the IV from repeating until the entire invocation field space of 2⁶⁴ is exhausted which can take hundreds of years. (In FIPS-CC Mode, SSH rekey is automatically configured at 1 GB of data or 1 hour, whichever comes first.)

In all the above cases, the nonce_explicit is always generated deterministically. AES GCM keys are zeroized when the module is power-cycled. For each new TLS or SSH session, a new AES GCM key is established.

Note: For specifics regarding what is supported in the Approved mode, see subsequent sections below in this document.

The cryptographic module supports the following non-FIPS Approved algorithms that are allowed for use in the Approved mode of operation:

Table 4 - FIPS Allowed Algorithms Used in the Approved Mode

FIPS Allowed Algorithms				
CMAC - A self-test is performed for this algorithm, but it is not used by the module.				
MD5 (within TLS)				
Non-Approved NDRNG (used to seed DRBG) This provides a minimum of 256 bits of entropy.				
RSA (key wrapping; key establishment methodology provides 112 or 128 bits of encryption strength)				

Table 5 - Supported Protocols in the Approved Mode

Supported Protocols*		
TLS 1.0**, 1.1, 1.2		
SSHv2		
SNMPv3		
IPsec and IKEv2 Note: IKEv1 was tested, but is not used by the module.		

(*): These protocols have not been tested or reviewed by the CMVP or the CAVP.

(**): See vendor imposed security rule in Security Rules section

Non-Approved, Non-Allowed Algorithms

The cryptographic module supports the following non-Approved algorithms. No security claim is made in the current module for any of the following non-Approved algorithms.

Table 6 - Non-FIPS Algorithms in Non-Approved Mode

Non-FIPS Algorithms in Non-Approved Mode

Digital Signatures (non-Approved strengths, non-compliant):

RSA Key Generation: 512, 1024, 4096

RSA signature generation: Modulus bit length less than 2048 or greater than 4096 bits; up to 16384 bits RSA signature verification: Modulus bit length less than 1024 or greater than 4096 bits; up to 16384 bits

ECDSA: B, K, P curves not equal to P-256, P-384 or P-521

DSA: 768 to 4096 bits

Encrypt/Decrypt - Triple-DES (non-compliant), CAST, Blowfish, Camellia, SEED, RC4

Hashing - MD5, RIPEMD

Key Exchange (non-Approved strengths):

Elliptic Curve Diffie-Hellman: B, K, P curves not equal to P-256, P-384 or P-521

Diffie-Hellman: 768, 1024 and 1536-bit modulus

RSA: Less than 2048-bit modulus

Message Authentication - HMAC-MD5, UMAC, HMAC-RIPEMD

4. Ports and Interfaces

The WF-500 provides the following ports and interfaces:




Figure 6 - Front Ports and Interfaces




Figure 7 - Rear Ports and Interfaces

Table 7 - WF-500 Ports and Interfaces

Interface	Quantity	FIPS 140-2	Name and Description
		Designation	

1	Power Button and Reset	2	Control input	Reboot or shut down device
2	Front LED Panel	4	Status output	Power, Power Failure, HDD, Overheat/Fan Failure
3	Drive LEDs	48	Status output	Left LED—drive failure Right LED—drive activity
4	Power	2	Power Input	Power supplies
5	DB9	1	Data input, Control input, Data output, Status output	Console (Note: In the Approved mode, the Console port is only available as Status output)
6	USB	4	Disabled except for power	Disabled except for power out
		1	Data input, Control input, Data output, Status output	MGT Ethernet 10/100/1000
		1	Data input, Data Output	Ethernet 1
7	RJ45	1	Data input, Control input, Data output, Status output	Ethernet 2
		1	Data input, Control input, Data output, Status output	Ethernet 3
8	VGA	1	N/A - Disabled	Graphic port (Note: Reserved for future use)
9	UID Button with LED	1	Control input, Status output	Button that activates LED on front and back of chassis to help identify physical location

5. Roles, Services, and Authentication

Assumption of Roles

The module supports distinct operator roles. The cryptographic module enforces the separation of roles using unique authentication credentials associated with operator accounts.

The module supports concurrent operators.

The module does not provide a maintenance role or bypass capability.

Table 8 - Roles and Authentication

Role	Description	Authentication Type	Authentication Data
Crypto- Officer (CO)	This role has read, write, execute, and delete capabilities for all Manager services. The CO has the ability to create other CO and User accounts that have limited service access.	Identity-based operator authentication	Username and password and/or Public Key Authentication
User	This User role has read-only access defined for a set of configuration and status information.	Identity-based operator authentication	Username and password and/or Public Key Authentication
Peer-to- peer VPN	Peer to peer VPN session for cluster.	Identity-based operator authentication	Certificate-based authentication

Table 9 - Strength of Authentication Mechanism

Authentication Mechanism	Strength of Mechanism
Username and Password	The minimum length of a password is six (6) characters¹ (95 possible characters). The probability that a random attempt will succeed or a false acceptance will occur is 1/(956), which is less than 1/1,000,000. The module supports a maximum of 10 failed attempts to authenticate into the module in a one (1) minute period. If the maximum number of attempts is reached, the operator is locked out for a configurable time period (one (1) minute to indefinitely). Therefore, the probability of successfully authenticating to the module within a one-minute period is 10/(956), which is less than 1/100,000.
Certificate/Public Key based authentication	The module supports authentication using RSA 2048, 3072, 4096 bits or ECDSA P-256/P-384/P-521. The minimum equivalent strength supported is 112 bits. The probability that a random attempt will succeed is $1/(2^{112})$, which is less than $1/1,000,000$. The probability of successfully authenticating to the module within a one (1) minute period is $6,000/(2^{112})$, which is less than $1/100,000$. The device supports up to 100 new sessions per second.

© 2022 Palo Alto Networks, Inc.

¹ In FIPS-CC Mode, the module checks and enforces the minimum password length of six (6) characters.

Security Parameters

The module contains the following keys and critical security parameters (CSP):

Table 10 – Private Keys and CSPs

CSP#	Key/CSP	Description
1	RSA/ECDSA Private keys	Private keys support establishment of TLS, IPSec/IKE, and SSH host authentication (RSA 2048, 3072, or 4096 bits; ECDSA P-256, P-384, or P-521)
2	TLS ECDHE/DHE Private Components	Ephemeral Diffie-Hellman private component (DH Group 14, L=2048, N >=224), (ECDHE P-256, P-384, P-521)
3	TLS Pre-Master Secret	Secret value used to derive the TLS Master Secret along with client and server random nonces
4	TLS Master Secret	Secret value used to derive the TLS session keys
5	TLS Encryption keys	AES (128 or 256-bit; CBC or GCM) session keys used in TLS connections
6	TLS HMAC keys	HMAC session keys (HMAC-SHA-1/SHA-256/SHA-384) used in TLS connections
7	SSH ECDH/DH Private Components	ECDH and Diffie-Hellman private component (DH 2048 bits, ECDH P-256, P-384, P-521)
8	SSH Session Encryption key	AES session keys used in SSH connections. (128, 192, or 256 bits; CBC, CTR) (128 or 256 bits: GCM)
9	SSH Session Authentication key	HMAC session keys used in SSH connections (HMAC-SHA-1, HMAC-SHA2-256, HMAC-SHA2-512)
10	CO, User Password	Password for operator authentication (minimum 6 characters)
11	DRBG Seed/State/Input String	DRBG seed and input string coming from the NDRNG and AES 256 CTR DRBG state (V and Key) used in the generation of a random values
12	SNMPv3 Secrets	SNMPv3 Authentication and Privacy Secrets (minimum 8 characters)
13	SNMPv3 Keys	AES Session and HMAC-SHA-1 Authentication Keys
14	IPSec/IKE Diffie-Hellman Private Components	Diffie-Hellman (Group 14) private components
15	IPSec/IKE EC Diffie-Hellman Private Components	EC Diffie-Hellman (Group 19, 20) private components

16	IPSec/IKE Session Keys	Encryption keys for session (128 or 256 bits: AES GCM or CBC)
17	IPSec/IKE Authentication Keys	HMAC keys for authentication (HMAC-SHA-256/384/512)
18	RADIUS Secret	Secret used by RADIUS (minimum length of six (6) characters)
19	Master Key	AES-256 CBC used to protect sensitive data

Table 11 - Public Keys

Key	Key Name	Description
А	RSA Public Keys / CA Certificates	RSA Public keys managed as certificates for the verification of signatures, establishment of TLS. (RSA 2048 bit minimum)
В	ECDSA Public Keys / CA Certificates	ECDSA public keys managed as certificates for verification of signatures and establishment of TLS. (ECDSA P-256, P-384, or P-521)
С	TLS ECDHE/DHE Public components	Ephemeral values used in key agreement. (DHE 2048, ECDHE P-256, P-384, P-521)
D	SSH ECDH/DH Public components	Used in key agreement. (2048 bits, P-256, P-384, P-521)
E	SSH Client RSA Public Key	Public key used to authenticate client. (RSA 2048, 3072, or 4096 bits)
F	SSH Host RSA/ECDSA Public key	SSH Host Public Key used to authenticate the host. (RSA 2048, 3072, or 4096 bits; ECDSA P-256, P-384, or P-521)
G	Firmware Authentication Key	RSA key used to authenticate firmware (2048 bits)
Н	Firmware Integrity Check Key	Used to check the integrity of the crypto-related code (HMAC-SHA-256* and ECDSA P-256) *Keys used to perform power-up self-tests are not CSPs as per IG 7.4
I	IPSec /IKE Diffie-Hellman Public Components	Diffie-Hellman (Group 14) public components.
J	IPSec /IKE EC Diffie-Hellman Public Components	Diffie-Hellman (Group 19, 20) public components.

Services

The Approved and non-Approved mode of operation provide identical services. While in the Approved mode of operation all authenticated services are accessed via SSH or TLS sessions. Approved and allowed algorithms, relevant CSPs and public keys related to these protocols are accessed to support the following services. CSP access by services is further described in the following tables.

The Crypto-Officer may access all services and has the ability to define multiple Crypto-Officer roles. The User role provides read-only access to the system via the System Audit service. The Peer-to-Peer VPN role consists in managing the establishment of VPN connections between several WildFire 9.0 WF-500 modules.

Table 12 - Authenticated Services

CO Services	Description	
System Operational Management	Perform system management functions including firmware updates, licensing, diagnostics and debug functions.	
System Configuration Management	Presents configuration options for management interfaces and communication for peer services. Import, Export, Save, Load, revert and validate configurations and state. Define access control methods via admin role profiles, configure administrators/users, and password profiles. Configure operators and authentication profiles	
Data Analysis Management	Configure data submission, analysis and reporting functions.	
Check Status	Review system, configuration, debug logs, and show configurations.	
User Services	Description	
System Audit	Allows review of limited configuration and system status via logs, dashboard and configuration screens. Provides no configuration commit capability.	
Peer-to-Peer VPN Services	Description	
IKE/IPsec configuration	Configures IKE/IPsec setup for peer to peer VPN.	

Table 13 - Unauthenticated Services

Service	Description	
Zeroize	The device will overwrite all CSPs. The zeroization procedure is invoked when the operator performs a factory reset or exits out of the Approved mode of operation. The operator must be present to observe that the method has completed successfully, or the operator must be in control of the module via a remote management session. During the zeroization procedure, no other services are available.	
Self-Tests	Run power up self-tests on demand by power cycling the module.	
Show Status	View hardware status of the module via the LEDs.	

CSP Access Rights

The following table defines the access to CSPs and the different module services. While in the Approved mode, all authenticated services and CSPs are accessed via authenticated TLS or SSH sessions. Approved and allowed algorithms, relevant CSPs, and public keys related to these protocols are used to access the services as listed in **Error! Reference source not found.**. The modes of access shown in the table are defined as:

R = Read: The module reads the CSP. The read access is performed when a CSP is either exported from the module or executed by a security function.

W = Write: The module writes the CSP. The write access is performed after a CSP is either imported into the module, generated by the module, or if the module overwrites an existing CSP.

Table 14 - CSP and Public Key Access Rights within Roles and Services

Role	Authorized Service	CSP Access
СО	System Operational Management	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 14, 15, 16, A, B, C, D, E, F, G, H, I, J - RW F, H - R
СО	System Configuration Management	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, F, G - RW
СО	Data Analysis Management	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11 - RW
СО	Check Status	1, 7, 8, 9, 10, 11, 12, 13 - R
User	System Audit	1, 7, 8, 9,10, 11 – R (W possible for User Password only)
Peer to Peer VPN	IKE/IPsec configuration	1, 11, 14, 15, 16, 17, A, B, I, J - RW
Unauthenticated	Zeroize	All CSPs are zeroized.
Unauthenticated	Self-Tests	H-R
Unauthenticated	Show Status (LEDs)	N/A

6. Operational Environment

The FIPS 140-2 Area 6 Operational Environment requirements are not applicable. The operational environment is limited since the Module includes a firmware load service to support necessary updates. New firmware versions within the scope of this validation must be validated through the FIPS 140-2 CMVP. Any other firmware loaded into this module is out of the scope of this validation and requires a separate FIPS 140-2 validation.

7. Self-Tests / Security Rules

The module design corresponds to the module security rules. This section documents the security rules enforced by the cryptographic module to implement the security requirements of a FIPS 140-2 Level 2 module.

- 1. The cryptographic module shall provide distinct operator roles. When the module has not been placed in a valid role, the operator shall not have access to any cryptographic services.
- 2. The cryptographic module shall clear previous authentications on power cycle.
- 3. The cryptographic module shall perform the following tests:
 - A. Power up Self-Tests
 - 1. Cryptographic algorithm tests
 - a. AES Encrypt Known Answer Test
 - b. AES Decrypt Known Answer Test
 - c. AES CMAC Known Answer Test
 - d. AES GCM Encrypt Known Answer Test
 - e. AES GCM Decrypt Known Answer Test
 - f. AES CCM Encrypt Known Answer Test
 - g. AES CCM Decrypt Known Answer Test
 - h. RSA Sign Known Answer Test

- i. RSA Verify Known Answer Test
- j. RSA Encrypt Known Answer Test
- k. RSA Decrypt Known Answer Test
- I. ECDSA Sign Known Answer Test
- m. ECDSA Verify Known Answer Test
- n. DH Known Answer Test
- o. HMAC (HMAC-SHA-1/256/384/512) Known Answer Test
- p. SHA-1 Known Answer Test
- q. SHA-256 Known Answer Test
- r. SHA-384 Known Answer Test
- s. SHA-512 Known Answer Test
- t. DRBG Known Answer Test
- u. ECDH Known Answer Test
- v. SP 800-90A Section 11.3 Health Tests
- B. Firmware Integrity Test HMAC-SHA-256 and ECDSA P-256.
- C. Critical Functions Tests
 - 1. N/A
- D. Conditional Self-Tests
 - Continuous Random Number Generator (RNG) test performed on NDRNG and DRBG, 128 bits
 - 2. Firmware Load Test Verify RSA 2048 signature on firmware at time of load
 - 3. RSA Pairwise Consistency Test
 - 4. ECDSA Pairwise Consistency Test
 - 5. If any conditional test fails, the module will output a description of the error.

If any self-tests or conditional test fails, the module will output 'FIPS-CC failure' and the specific test that failed.

- 4. Power-up self-tests shall not require any operator action.
- 5. The operator shall be capable of commanding the module to perform the power-up self-test by power cycling the module.
- 6. Data output shall be inhibited during power-up self-tests and error states.
- 7. Processes performing key generation and zeroization processes shall be logically isolated from the logical data output paths.
- 8. The module does not output intermediate key generation values.
- 9. Status information output from the module shall not contain CSPs or sensitive data that if misused could lead to a compromise of the module.
- 10. There are no restrictions on which keys or CSPs are zeroized by the zeroization service.
- 11. The module maintains separation between concurrent operators.
- 12. The module does not support a maintenance interface or role.
- 13. The module does not have any external input/output devices used for entry/output of data.
- 14. The module does not allow the input or output of plaintext CSPs.
- 15. The module provides a warning, "Your device is still configured with the default admin account credentials. Please change your password prior to deployment." to inform the operator to change their default authentication data.

Vendor imposed security rules:

- 16. If the cryptographic module remains inactive in any valid role for the administrator specified time interval, the module automatically logs out the operator.
- 17. The module enforces a timed access protection mechanism that supports at most ten authentication attempts per minute. After the administrator-specified number of consecutive unsuccessful password validation attempts have occurred, the cryptographic module shall enforce a wait period of at least one (1) minute before any more login attempts can be attempted.
- 18. In FIPS-CC mode, the following rules shall apply:
 - A. The operator should not enable TLSv1.0; it is disabled by default.

 Note that TLSv1.0 can be used in an Approved mode of operation (Approved TLS KDF algorithm); however, TLSv1.0 protocol is no longer considered as secure because of the Cipher Block Chaining IV attack, a client of the module could use a vulnerable implementation.
 - B. If using RADIUS, it must be configured using TLS. If RADIUS without TLS protocol is set, the module shall be configured in non-Approved mode of operation.
 - C. The operator shall not generate 4096-bit RSA key in FIPS-CC mode. If the operator wants to generate 4096-bit RSA key, the module shall be configured in non-Approved mode of operation.

8. Physical Security

Physical Security Mechanisms

The multi-chip standalone module is production quality and contains standard passivation. Chip components are protected by an opaque enclosure. There are tamper-evident seals that are applied on the module by the Crypto-Officer, and any unused seals are to be controlled by the Crypto-Officer. The Crypto-Officer must ensure that the module surface is clean and dry before applying the seals. The seals prevent removal of the opaque enclosure without evidence, which should be inspected by the Crypto-Officer every 30 days for evidence of tamper. If the seals or opacity shields show evidence of tamper, the Crypto-Officer should assume that the module has been compromised and contact Customer Support.

Note: For ordering information, see Table 1 for FIPS kit part numbers and version. Opacity shields are included in the FIPS kits.

Refer to Appendix A for instructions regarding installation of the tamper seals and opacity shields. Tamper-evident seals must be pressed firmly onto the adhering surfaces during installation, and once applied, the Crypto-Officer shall permit 24 hours of cure time for all tamper-evident seals. The placement of the twelve (12) tamper-evident seals are shown in Appendix A.

Operator Required Actions

The following table provides information regarding the various physical security mechanisms, and their recommended frequency of inspection/test.

Model	Physical Security Mechanism	Recommended Frequency of Inspection/Test	Inspection/Test Guidance Details
WF-500	Tamper-Evident Seals	30 days	Verify integrity of tamper-evident seals in the locations specified in Appendix A.

Table 15 - Inspection/Testing of Physical Security Mechanisms

WF-500	Front and Rear Opacity Shields	30 days	Verify that the front and rear opacity shields have not been deformed from their original shape, thereby reducing their effectiveness.
WF-500	Vent Overlays	30 days	Verify that the vent overlays have not been removed or deformed. All edges should maintain strong adhesion characteristics.

9. Mitigation of Other Attacks

The module is not designed to mitigate any specific attacks outside the scope of FIPS 140-2. These requirements are not applicable.

10. References

[FIPS 140-2] FIPS Publication 140-2 Security Requirements for Cryptographic Modules

11. Definitions and Acronyms

AES - Advanced Encryption Standard

CA - Certificate Authority

CLI - Command Line Interface

CO - Crypto-Officer

CSP - Critical Security Parameter

CVL - Component Validation List

DB9 - D-sub series, E size, 9 pins

DES - Data Encryption Standard

DH - Diffie-Hellman

DRBG - Deterministic Random Bit Generator

EDC - Error Detection Code

ECDH - Elliptical Curve Diffie-Hellman

ECDSA - Elliptical Curve Digital Signature Algorithm

FIPS - Federal Information Processing Standard

HMAC - (Keyed) Hashed Message Authentication Code

KDF - Key Derivation Function

LED - Light Emitting Diode

NDRNG - Non-Deterministic Random Number Generator

RJ45 - Networking Connector

RNG -Random number generator

RSA - Algorithm developed by Rivest, Shamir and Adleman

SHA - Secure Hash Algorithm

SNMP - Simple Network Management Protocol

SSH - Secure Shell

TLS - Transport Layer Security

USB - Universal Serial Bus

VGA - Video Graphics Array

Appendix - WF-500 FIPS Kit Installation Guide (12 Tamper-Evident Seals)

This section provides steps on how to install the FIPS Kit on the WF-500 module.

Step 1:

Remove the two pull handles and front modules on the left and right side of the appliance by removing the three (3) screws located behind each handle/module. There is no need to disconnect the LED circuit board attached to the end of the ribbon cable. Retain these screws for Step 2.




Figure 8 - Remove Front Handles and Modules

Step 2:

Attach the left and right front cover brackets to the appliance using the six (6) screws that were removed in Step 1. First attach the brackets using the bottom screws (one (1) on each side) as shown in Figure 9, ensuring that you feed the ribbon cable and LED circuit board through the left bracket. Replace the front modules and secure them using the middle and top screws on each side as shown in Figure 10.




Figure 9 - Secure the Front Brackets





Figure 10 - Attach Pull Handles and Front Modules

Step 3: Secure the front opacity shield to the right and left front brackets that you installed in Step 2. Use two (2) screws (provided) on each side. Figure 11 - Install Front Opacity Shield Figure 12 - Front Opacity Shield Installed

Step 4:


Attach the rear opacity shield tray to the appliance. First, remove the two (2) screws (shown in Figure 13) from the appliance and use these screws to secure the rear opacity shield tray.

Note: Install the back cables (power cords and network/management cables) because you will not be able to access these ports after the next step.



Step 5:

Place the rear opacity shield on top of the rear opacity shield tray ensuring that you run the cables through the opening at the bottom. Secure the opacity shields with two (2) screws (provided) on each side.



Step 6:

Cover the vent openings as shown in Figure 15 by applying one (1) overlay tamper-evident seal over the left side vent and one overlay tamper-evident seal over the right side vent. Each overlay requires two (2) tamper-evident seals as shown in Figure 16. Also apply one (1) additional tamper-evident seal as shown in Figure 16, #5.





Figure 15 - Apply Tamper-Evident Seals on Vent Overlays



Step 7:

Attach the rail kit to the appliance as shown in Figure 17 and then add three (3) tamper-evident seals to the bottom of the appliance as shown in Figure 18. One (1) tamper-evident seal prevents tampering of the front opacity shield connected to the bottom of the appliance and two (2) tamper-evident seals wrap around the upper and lower rear opacity shields to prevent tampering of the rear opacity shields.




Figure 17 - Install Rail Kit




Figure 18 - Apply Tamper-Evident Seals on the Bottom of the Appliance