IBM LTO Generation 4 Encrypting Tape Drive

Security Policy

Version 3 Revision 5

1	Docur	ment History	
2	2.1 References		
		References Document Organization	
3	LTO (Generation 4 Encrypting Tape Drive Cryptographic Module Description	4
	3.1	Overview	4
	3.2	Secure Configuration	6
	3.3	Ports and Interfaces	9
	3.4	Roles and Services	
	3.5	Physical Security	17
	3.6	Cryptographic Algorithms and Key Management	
	3.7	Design Assurance	21
	3.8	Mitigation of other attacks	21

1 Document History

Date	Author	Change
08/20/2007	Christine Knibloe	Initial Creation
12/10/2007	Christine Knibloe	V1.1
		Corrected External Key Manager
		Correct bypass information
		BAB port clarification
06/13/2008	Christine Knibloe	V2.0
		Incorporate feedback
09/17/2008	Christine Knibloe	V3.0
		Incorporate all host interfaces
		Incorporate panel feedback
		Added GCM information
		Added standalone module
		Modified security parameter table
11/11/2008	Christine Knibloe	V3.1
		Update tables and diagrams
11/17/2008	Christine Knibloe	V3.2
		Update Security Parameters table
12/01/2008	Christine Knibloe	V3.3
		Update Self-Test table
04/10/2009	Christine Knibloe	V3.4
		Incorporate CMVP comments.
		Inserted tables.
6/1/2009	Christine Knibloe	V3.5
		Incorporate CMVP comments.

2 Introduction

This non-proprietary security policy describes the IBM LTO Generation 4 Encrypting Tape Drive cryptographic module and the approved mode of operation for FIPS 140-2, security level 1 requirements. This policy was prepared as part of FIPS 140-2 validation of the LTO Gen4. The LTO Gen4 Encrypting Tape Drive is referred to in this document as the LTO Gen4, the IBM LTO Gen4, and the encrypting tape drive.

FIPS 140-2 (Federal Information Processing Standards Publication 140-2—Security Requirements for Cryptographic Modules) details the U.S. Government requirements for cryptographic modules. More information about the FIPS 140-2 standard and validation program is available on the NIST web site at:

http://csrc.nist.gov/groups/STM/cmvp/index.html

The security policy document is organized in the following sections. Introduction

- References
- Document Organization

LTO Gen4 Encrypting Tape Drive Cryptographic Module Description

- Cryptographic Module Overview
- Secure Configuration
- Cryptographic Module Ports and Interfaces
- Roles and Services
- Physical Security
- Cryptographic Key Management
- Self-Tests
- Design Assurance
- Mitigation of Other Attacks

2.1 References

This document describes only the cryptographic operations and capabilities of the LTO Gen4 Encrypting Tape Drive. More information is available on the general function of the LTO Gen4 Encrypting Tape Drive at the IBM web site:

http://www.ibm.com/storage/tape/

The tape drive meets the T10 SCSI-3 Stream Commands (SSC) standard for the behavior of sequential access devices.

The LTO Gen4 Encryption Tape Drive supports 3 host interface types: Ultra320 Small Computer System Interface (SCSI), fibre channel (FC), and serial-attached SCSI (SAS). The physical and protocol behavior of these ports conforms to their respective specifications. These specifications are available at the INCITS T10 standards web site:

http://www.T10.org/

A Redbook describing tape encryption and user configuration of the LTO Gen4 drive in various environments can be found at:

http://www.redbooks.ibm.com/abstracts/sg247320.html?Open

The LTO Gen4 drive format on the tape media is designed to conform to the IEEE P1619.1 committee draft proposal for recommendations for protecting data at rest on tape media. Details on P1619.1 may be found at:

http://ieee-p1619.wetpaint.com/

2.2 Document Organization

The Security Policy document is one document in a FIPS 140-2 Submission Package. In addition to this document, the submission package contains:

- Vendor Evidence Document
- Other supporting documentation and additional references

With the exception of this Non-Proprietary Security Policy, the FIPS 140-2 Validation Documentation is proprietary to IBM and is releasable only under appropriate non-disclosure agreements. For access to these documents, contact IBM.

3 LTO Generation 4 Encrypting Tape Drive Cryptographic Module Description

3.1 Overview

The LTO Gen4 Encrypting Tape Drive is a set of hardware, firmware, and interfaces allowing the optional storage and retrieval of encrypted data to magnetic tape cartridges. The entire "brick" unit of the LTO Gen4 tape drive is FIPS 140-2 validated as a multi-chip, standalone cryptographic module. In customer operation the "brick" unit may be embedded in bridge box or in a canister package for operation in a library. Block diagrams of the LTO Gen4 Encrypting Tape Drive are shown below:

Cryptographic Module Block Diagram




Figure 1a: LTO Gen4 Ultra320 SCSI Drive Block Diagram

_			

Cryptographic Module Block Diagram




Figure 2b: LTO Gen4 Fibre Channel Drive Block Diagram

Cryptographic Module Block Diagram




Figure 3c: LTO Gen4 SAS Drive Block Diagram

The LTO Gen4 Encrypting Tape Drive has two major cryptographic functions:

- Data Block Cipher Facility: The tape drive provides functions which provide the ability for standard tape data blocks as received during SCSI-type write commands to be encrypted before being recorded to media using AES-GCM block cipher using a provided key, and decrypted during reads from tape using a provided key.
 - Note the AES-GCM block cipher operation is performed after compression of the host data therefore not impacting capacity and data rate performance of the compression function
 - The LTO Gen4 drive automatically performs a complete and separate decryption and decompression check of host data blocks after the compression/encryption process to validate there were no errors in the encoding process
- Secure Key Interface Facility: The tape drive provides functions which allow authentication of the tape drive to an external IBM key manager, such as the IBM Encryption Key Manager (EKM) or the Tivoli Key Lifecycle Manager (TKLM), and allow transfer of protected key material between the key manager and the tape drive.

3.2 Secure Configuration

This section describes the approved mode of operation for the LTO Gen4 drive to maintain FIPS 140-2 validation.

There are two configurations for the LTO Gen4 in the approved mode of operation. They are:

- System-Managed Encryption (SME)
- Library-Managed Encryption (LME)

There are two different methods an operator may use to select one of the configurations. The first is configuring the drive's VPD via the library interface. The second method is issuing a SCSI Mode Select command to set values in Mode Page X'25'.

In order to be in the approved mode of operation, one of the aforementioned configurations (SME or LME) must be enabled and the values of the fields Key Path (manager Type) (from VPD), In-band Key Path (Manager Type) Override, Indirect Key Mode Default, Key Scope, and Encryption Method must be set according to the table below. More details can be found in the LTO Ultrium Tape Drive SCSI Reference.

Table 1: Settings for Approved Configurations

Required Fields	System-Managed Encryption (SME)	Library-Managed
Key Path (Manager Type) (from VPD)	X'1'	Encryption (LME) X'6'
Mode Page X'25', byte 21, bits 7-5		0
In-band Key Path (Manager Type) Override	X'0' or X'1'	X'0'
Mode Page X'25', byte 21, bits 4-2		
Indirect Key Mode Default	B'0'	B'0'
Mode Page X'25', byte 22, bit 4		
Key Scope	X'0' or X'1'	X'0' or X'1'
Mode Page X'25', byte 23, bits 2-0		
Encryption Method	X'10' or X'1F'	X'60'
Mode Page X'25', byte 27		

A user can determine if the LTO Gen4 is in the approved mode of operation by issuing a SCSI Mode Sense command to Mode Page X'25' and evaluating the values returned.

Certain commands are prohibited while in the approved mode of operation. The commands vary based on which configuration is used in the approved mode. In the LME configuration, all Mode Select commands to subpages of Mode Page X'25' are prohibited. In the SME configuration, Mode Select commands to the following subpages of Mode Page X'25' are prohibited.

Table 2: Mode Select Eligibility of Mode Page X'25' Subpages

Mode Page X'25' Subpages	System-Managed Encryption (SME)	Library-Managed Encryption (LME)
X'C0' – Control/Status	Allowed	Prohibited
X'D0' – Generate dAK/dAK' Pair	Prohibited	Prohibited
X'D1' – Query dAK	Prohibited	Prohibited
X'D2' – Update dAK/dAK' Pair	Prohibited	Prohibited
X'D3' – Remove dAK/dAK' Pair	Prohibited	Prohibited
X'D5' – Drive Challenge/Response	Allowed	Prohibited
X'D6' – Query Drive Certificate	Allowed	Prohibited
X'D7' – Query/Setup HMAC	Prohibited	Prohibited
X'D8' – Install eAK	Prohibited	Prohibited
X'D9' – Query eAK	Prohibited	Prohibited
X'DA' – Update eAK	Prohibited	Prohibited
X'DB' – Remove eAK	Prohibited	Prohibited
X'DF' – Query dSK	Allowed	Prohibited
X'E0' – Setup SEDK	Allowed	Prohibited
X'E1' – Alter DKi	Allowed	Prohibited
X'E2' – Query DKi (Active)	Allowed	Prohibited
X'E3' – Query DKi (Needed)	Allowed	Prohibited
X'E4' – Query DKi (Entire)	Allowed	Prohibited
X'E5' – Query DKi (Pending)	Allowed	Prohibited
X'EE' – Request DKi (Translate)	Allowed	Prohibited
X'EF' – Request DKi (Generate)	Allowed	Prohibited
X'FE' – Drive Error Notify	Allowed	Prohibited

Loading a FIPS-validated drive microcode level and configuring the drive for SME or LME operation initializes the LTO Gen4 into the approved mode of operation.

The LTO Gen4 supports multi-initiator environments, but only one initiator may access cryptographic functions at any given time. Therefore the LTO Gen4 does not support multiple concurrent operators.

The LTO Gen4 implements a non-modifiable operational environment which consists of a firmware image stored in FLASH. The firmware image is copied to, and executed from, RAM. The firmware image can only be updated via FIPS-approved methods that verify the validity of the image.

The LTO Gen4 drive brick operates as a stand-alone tape drive and has no direct dependency on any specific operating system or platform for FIPS approved operating mode, but does have requirements for:

- Key Manager/Key Store attachment
- Drive Configuration

The following criteria apply to the usage environment:

- Key Manager and Key Store Attachment
 - In both SME and LME configurations, an IBM key manager, such as the Encryption Key Manager (EKM) or the Tivoli Key Lifecycle Manager (TKLM), and a supported key store must be used in a manner which supports secure import and export of keys with the LTO Gen4 drive:
 - Keys must be securely passed into the LTO Gen4 drive. The key manager must support encryption of the Data Key to form a Session Encrypted Data Key (SEDK) for transfer to the LTO Gen4. The SEDK is created by encrypting the Data Key using the public Session Key to perform 2048-bit RSA encryption.
 - The key manager/key store must be able to use the Data Key index (DKi) it supplies the drive to determine the Data Key.
- Drive Configuration requirements
 - The LTO Gen4 drive must be configured for SME or LME operation.
 - The LTO Gen4 drive must have the FIPS 140-2 validated drive firmware level loaded and operational.
 - O Drive must be configured in the approved mode of operation.
 - o In LME configuration, the LTO Gen4 drive must be operated in an automation device which operates to the LDI or ADI interface specifications provided.

		Г	T	Γ	
_					

3.3 Ports and Interfaces

The cryptographic boundary of the LTO Gen4 drive cryptographic module is the drive "brick" boundary and therefore supports all the interfaces of a standard tape drive. Tape data blocks to be encrypted (write operations) or decrypted data blocks to be returned to the host (read operation) are transferred on the host interface ports using SCSI commands, while protected key material may be received on the host interface ports or the library port.

The physical ports are separated into FIPS-140-2 logical ports as described below.

Table 3: Ports Common to All Host Interface Types

LTO Gen4 Drive	FIPS-140-2	Crypto	Interface Functionality
Physical Ports	Logical Interface	Services	
BAB Port	Disabled by FIPS approved firmware levels.	None	■ Disabled by FIPS approved firmware levels.
RS-422 Port	Data Input Data Output Control Input Status Output	Yes	 Inputs data Crypto: Inputs protected keys from the key manager in LME configuration. Outputs data Outputs encrypted key components Inputs LDI and LMI protocol commands. Outputs LDI and LMI protocol status.
RS-232 Port	Disabled by FIPS approved firmware levels.	None	■ Disabled by FIPS approved firmware levels.
Threader Power Port	Power	None	 Supplies power to threader unit internal to tape drive brick.
Input Power Port	Power	None	■ Inputs power to the LTO Gen4 drive
Write Protect Switch	Control Input	None	■ Inputs write protect state of the cartridge
Front Panel Single- Character Display (SCD)	Status Output	None	Displays status
Front Panel Amber LED	Status Output	None	■ Displays status
Front Panel Green LED	Status Output	None	■ Displays status
Front Panel Unload Button	Control Input	None	 Inputs unload command Places the drive in manual diagnostic mode Scrolls through manual diagnostics Exits manual diagnostic mode Forces drive dump Resets the drive
Read/Write Head	Data Input Data Output	None	 Inputs data from tape cartridges Outputs data to tape cartridges Inputs command to load firmware from special FMR cartridges Encrypted data is recorded to media or read back from media on this interface

Table 4a: Ultra320 SCSI-Specific Host Interface Ports

LTO Gen4	FIPS-140-2	Crypto	Interface Functionality
Ultra320 SCSI	Logical Interface	Services	
Drive			
Physical Ports			
SCSI Port	Data Input	Yes	■ Inputs data
	Data Output		Crypto: Inputs protected keys from the key
	Control Input		manager in SME configuration.
	Status Output		Outputs data
			 Outputs encrypted key components
			■ Inputs SSC-3 SCSI protocol commands
			 Outputs SSC-3 SCSI protocol status
SCSI ID Port	Control Input	None	 Inputs SCSI ID control parameters
Feature Switches	Control Input	None	■ Inputs RS-422 interface control parameters
			 Inputs SCSI interface control parameters
			 Inputs read/write head cleaner brush control
			parameters

Table 4b: Fibre Channel-Specific Host Interfaces Ports

LTO Gen4 FC	FIPS-140-2	Crypto	Interface Functionality
Drive	Logical Interface	Services	
Physical Ports			
Fibre Channel Port	Data Input		■ Inputs data
0	Data Output	Yes	<u>Crypto</u>: Inputs protected keys from the key
Fibre Channel Port	Control Input		manager in SME configuration.
1	Status Output		Outputs data
			Outputs encrypted key components
			■ Inputs SSC-3 SCSI protocol commands
			 Outputs SSC-3 SCSI protocol status
Fibre Channel	Control Input		 Inputs fibre channel interface control parameters
Loop ID Port	Status Output	None	 Outputs fibre channel interface status
Fibre Channel Link	Control Input		 Inputs fibre channel interface control parameters
Characteristics Port		None	
Feature Switches	Control Input		■ Inputs RS-422 interface control parameters
		None	 Inputs fibre channel interface control parameters
			 Inputs read/write head cleaner brush control
			parameters

Table 4c: SAS-Specific Host Interfaces Ports

LTO Gen4 SAS drive Physical Ports	FIPS-140-2 Logical Interface	Separation of Logical Interfaces
SAS Connector	Data Input	Physical separation:
	Data Output	Pins P1-P15 are power input
	Control Input	Pins S1-S7 are SAS Port 0
	Status Output	Pins S8-S14 are SAS Port 1
	Power	Logical Separation (SAS Ports):
		■ T10 SAS Standards
Feature Switches	Control Input	N/A

3.4 Roles and Services

The LTO Gen4 drive supports both a Crypto Officer role and a User role, and uses basic cryptographic functions to provide higher level services. For example, the LTO Gen4 drive uses the cryptographic functions as part of its data reading and writing operations in order to perform the encryption/decryption of data stored on a tape.

The Crypto Officer role is implicitly assumed when an operator performs key zeroization. The User role is implicitly assumed for all other services.

The two main services the LTO Gen4 drive provides are:

- Encryption or decryption of tape data blocks using the Data Block Cipher Facility.
- Establishment and use of a secure key channel for key material passing by the Secure Key Interface Facility.

It is important to note that the Secure Key Interface Facility may be an automatically invoked service when a user issues Write or Read commands with encryption enabled that require key acquisition by the LTO Gen4 drive. Under these circumstances the LTO Gen4 drive automatically establishes a secure communication channel with a key manager and performs secure key transfer before the underlying write or read command may be processed.

3.4.1 User Guidance

The services table describes what services are available to the User and Crypto Officer roles.

- There is no authentication required for accessing the User Role
- There is no authentication required for accessing the Crypto Officer Role

Single Operator requirements:

• The LTO Gen4 drive enforces a requirement that only one host interface initiator may have access to cryptographic services at any given time.

T	T	T	<u> </u>	<u> </u>
I	l .	I		

3.4.2 Provided Services

Available services are also documented in the specified references. They are summarized here:

Table 5: Provided Services

Service	Interface(s)	Description	Inputs	Outputs	Role
General SCSI	- Host	As documented in the	Formatted	Formatted	User
commands		LTO Ultrium Tape Drive	Operational	Operational	
		SCSI Reference	Codes and	Codes and	
			Messages	Messages	
General Library	- Library	As documented in the	Formatted	Formatted	User
Interface commands		Drive Library LDI and	Operational	Operational	
		LMI Interface	Codes and	Codes and	
		Specifications	Messages	Messages	
Unload via Button	- Front Panel	Unload via unload button	Button press	Green LED	User
	Unload			flashes	
	Button			while	
				unload is in	
51 1 1 1				progress.	
Places the drive in	- Front Panel	Place in manual	Button press	SCD	User
manual diagnostic	Unload	diagnostic mode via the		displays 0.	
mode	Button	unload button		Amber LED	
				becomes	
C 11 - 41 1-	E	C 11 41 1 1	D44	solid.	TT
Scrolls through	- Front Panel Unload	Scroll through manual	Button press	SCD	User
manual diagnostic		diagnostic functions via the unload button		changes to	
functions	Button	the unload button		indicate	
Exits manual	- Front Panel	Exit manual diagnostic	Button press	scrolling.	User
diagnostic mode	Unload	mode via the unload	Button press	becomes	Usei
diagnostic mode	Button	button		blank.	
	Dutton	button		Green LED	
				becomes	
				solid.	
Forces drive dump	- Front Panel	Force a drive dump via	Button press	SCD shows	User
Torces arrive damp	Unload	the unload button	Button press	0. then	0501
	Button			becomes	
				blank.	
Resets the drive	- Front Panel	Power-cycle the device	Button press	Reboot	User
	Unload	via Unload Button	F	occurs.	
	Button				
LED status display	- Front Panel	Display Power-On status	From LTO	On or off	User
	Unload	via LED	Gen4 drive		
	Button		operating		
			system		
Single-Character	- Front Panel	Display status via Single-	From LTO	Single-	User
Display (SCD)	Unload	Character Display	Gen4 drive	character	
	Button		operating	status	
			system	messages	

Service	Interface(s)	Description	Inputs	Outputs	Role
Encrypting Write-	- Host	The Secure Key Interface	- Plaintext	- Encrypted	User
type Command		Facility automatically	data	data on tape	
		requests a key, provides	- SEDK	- DKi on	
		authentication data,	- DKi	tape	
		securely transfers and			
		verifies the key material.			
		The Data Block Cipher			
		Facility encrypts the data			
		block with the received			
		Data Key using AES-			
		GCM block cipher for recording to media. A			
		received DKi is			
		automatically written to			
		media using the Cartridge			
		memory and the RW			
		Head Interface.			
		The decryption-on-the-			
		fly check performs AES-			
		GCM decryption of the			
		encrypted data block and			
		verifies the correctness of			
		the encryption process			
Decrypting Read-	- Host	The Secure Key Interface	SEDK	- Plaintext	User
type Command		Facility automatically		data to host	
		requests a key, provides			
		authentication data and			
		DKi information if			
		available, securely			
		transfers and verifies the			
		key material.			
		The received Data Key is			
		used by the Data Block			
		Cipher Facility to decrypt			
		the data block with using AES-GCM decryption			
		and returning plaintext			
		data blocks to the host;			
		Optionally in Raw mode			
		the encrypted data block			
		may be returned to the			
		host in encrypted form			
		(not supported in			
		approved configuration)			
Set Encryption	- Host	Performed via Mode	Requested	None	User
Control Parameters	- Library	Select to Mode Page	Mode Page		
(including Bypass		x'25' and Encryption	and Subpage		
Mode)		Subpage X'C0'			
Query Encryption	- Host	Performed via Mode	Requested	Mode Data	User
Control Parameters	- Library	Sense to Mode Page	Mode Page		
(including Bypass		x'25' and Encryption	and Subpage		
Mode)		Subpage X'C0'			
"Show Status"					
Show Status	1		<u> </u>	L	

Service	Interface(s)	Description	Inputs	Outputs	Role
Show Status	- Front Panel	Visual indicators that an	From LTO	Visual	User
(Visual Indicators)	LEDs and	encryption operation is	Gen4 drive	indicators	
	Single-	currently in progress may	operating	on front	
	Character	be monitored on the front	system	panel	
D :	Display	panel	D . 1	MID	T.T.
Drive	- Host	Allows programming	Requested	Mode Data	User
Challenge/Response	- Library	challenge data and	Mode Page		
		reading an optionally) encrypted, signed	and Subpage		
		response; not used in			
		default configuration.			
		Performed via mode			
		select and mode sense to			
		Mode Page x'25' and			
		Encryption Subpage			
		x'D5'; not used in			
		default configuration			
Query Drive	- Host	Allows reading of the	Requested	Mode Data	User
Certificate	- Library	Drive Certificate public	Mode Page		
		key. Performed via mode	and Subpage		
		sense to Mode Page			
		x'25' and Encryption			
		Subpage x'D6'; the			
		provided certificate is			
		signed by the IBM Tape Root CA.			
Query dSK	- Host	Allows reading of the	Requested	Mode Data	User
Query usk	- Host - Library	Drive Session (Public)	Mode Page	Mode Data	Usei
	- Library	Key Performed via	and Subpage		
		mode sense to Mode	and Suopuge		
		Page x'25' and			
		Encryption Subpage			
		X'DF'.			
Setup SEDK	- Host	This is the means to	Requested	Mode Data	User
structure (a	- Library	import a protected private	Mode Page		
protected key		key to the LTO Gen4	and Subpage		
structure)		drive for use in writing			
		and encrypted tape or in			
		order to read a previously			
		encrypted tape.			
		Performed via mode			
		select to Mode Page			
		x'25' and Encryption Subpage x'E0'.			
		In this service, the			
		module generates a drive			
		session key pair. The			
		module then sends the			
		dSK to the key manager			
		where it is used to create			
		an SEDK. Then, the key			
		manager sends the SEDK			
		back to the module.			


Service	Interface(s)	Description	Inputs	Outputs	Role
Query DKi(s) –	- Host	Allows the reading from	Requested	Mode Data	User
active, needed,	- Library	the drive of DKi	Mode Page		
pending, entire (all)		structures in different	and Subpage		
		categories for the			
		medium currently			
		mounted. Performed by			
		Mode Select commands			
		to Mode Page x25' and			
		various subpages.			
Request DKi(s)	- Host	This status command is	Requested	Mode Data	User
Translate	- Library	used when the drive has	Mode Page		
		already notified the Key	and Subpage		
		Manager that it has read			
		DKi structures from a			
		mounted, encrypted tape			
		and needs them translated			
		to an SEDK and returned			
		for the drive to read the			
		tape. The key manager			
		issues this command to			
		read DKi structures			
		which the drive requires			
		to be translated by the			
		Key Manager and			
		subsequently returned to			
		the drive as an SEDK			
		structure to enable			
		reading of the currently			
		active encrypted area of			
		tape. Performed via			
		mode sense to Mode			
		Page x'25' and			
		Encryption Subpage			
		X'EE'.			
Request DKi(s)	- Host	This status command is	Requested	Mode Data	User
Generate	- Library	used when the drive has	Mode Page		
		already notified the Key	and Subpage		
		Manager that it requires			
		new SEDK and DKi			
		structures to process a			
		request to write an			
		encrypted tape. This			
		page provides			
		information about the			
		type of key the drive is			
		requesting. Performed			
		via mode sense to Mode			
		Page x'25' and			
		Encryption Subpage			
		X'EF'.			1

Service	Interface(s)	Description	Inputs	Outputs	Role
Alter DKi(s)	- Host - Library	This command is used to modify the DKi structures stored to tape and cartridge memory. The LTO Gen4 drive will write the modified structures out to the tape and cartridge memory as directed. Performed via mode sense to Mode Page x'25' and Encryption Subpage x'E1'.	Requested Mode Page and Subpage	Mode Data	User
Drive Error Notify and Drive Error Notify Query	- Host - Library	These status responses are the means used by the drive to notify the Key Manager that an action is required, such as a Key generation or Translate, to proceed with an encrypted write or read operation. These status responses are read via Mode Sense commands to Mode Page x'25' subpage 'EF" and 'FF'.	Requested Mode Page and Subpage	Mode Data	User
Power-Up Self-Tests	- Power - Host - Library	Performs integrity and cryptographic algorithm self-tests, firmware image signature verification	None required	Failure status, if applicable	User, Crypto Officer
Configure Drive Vital Product Data (VPD) settings	- Host - Library	Allows controlling of default encryption mode and other operating parameters	From LTO Gen4 drive operating system	Vital Product Data (VPD)	User
Key Path Check diagnostic	- Host	As documented in the LTO Ultrium Tape Drive SCSI Reference	Diagnostic command specifying the Key Path diagnostic	Diagnosite command status	User
Key Zeroization	- Host	Zeroes all private plaintext keys in the LTO Gen4 drive via a Send Diagnostic command with Diagnostic ID EFFFh, as documented in the IBM TotalStorage LTO Ultrium Tape Drive SCSI Reference.	Diagnostic command specifying the Key Zeroization	Diagnosite command status	Crypto Officer

L			

3.5 Physical Security

The LTO Gen4 drive cryptographic boundary is the drive "brick" unit. The drive brick unit has industrial grade covers, and all the drive's components are production grade. The LTO Gen4 drive requires no preventative maintenance, and field repair is not performed for the unit. The drive brick covers are not removed in the field in the approved configuration. All failing units must be sent intact to the factory for repair.






Figure 2 LTO Gen4 Drive Brick

3.6 Cryptographic Algorithms and Key Management

3.6.1 Cryptographic Algorithms

The LTO Gen4 drive supports the following basic cryptographic functions. These functions are used by the Secure Key Interface Facility or the Data Block Cipher Facility to provide higher level user services.

Table 6: Basic Cryptographic Functions

Algorithm	Type /Usage	Specification /	Performed by	Algorithm
		Approved	/ Used by	Certificate
AES-ECB mode Encryption / decryption (256-bit keys)	Used as the underlying cipher for AES-GCM. Not available as a separate service.	AES: FIPS-197	ASIC	#918 and #919
AES-GCM mode encryption / decryption (256-bit keys)	Symmetric Cipher Encrypts data blocks while performing decrypt-on-the-fly verification Decrypts data blocks	AES: FIPS-197 GCM: SP800-38D	ASIC	AES Certs. #918 and #919; vendor- affirmed
PRNG	IV generation for AES- GCM, Drive Session Key generation	FIPS 186-2 using SHA-1	Firmware	#527
SHA-1	Hashing Algorithm Multiple uses	FIPS 180-2	Firmware	#906
SHA-256	Hashing Algorithm Digest checked on key manager messages, digest appended on messages to key manager	FIPS 180-2	Firmware	#906
PKCS #1 :RSA Key Generation (1024/2048-bit keys)	Key Generation Session key generation	Non-approved (but may be used if used only for encryption)	Firmware	N/A
PKCS #1 :RSA Sign/Verify	Digital signature signing and verification Used to sign the session key with dCert' Verifies firmware image signature before use on new firmware image load	Approved	Firmware	#446
PKCS #1 RSA Encryption/Decryption (1024/2048-bit keys)	Decryption of transported key material SEDK decrypt	Non-approved (but may be used in FIPS mode for key transport)	Firmware	N/A
TRNG (Custom)	Seeding PRNG	Non-Approved	ASIC	N/A

l .		

3.6.2 Security Parameters

The following table provides a summary of both critical security parameters (CSPs) and non-critical security parameters used by the LTO Gen4 drive.

Table 7: Security Parameters

Security Parameter	CSP		Input into Module	Output from Module	Generation Method	Storage Location	Storage Form	Zeroized
Drive Certificate Public Key (dCert)	No	RSA 2048-bit PKCS#1	Yes - at time of manufacture	Yes	N/A	Drive Vital Product Data (VPD)	Non-volatile Plaintext	N/A
Drive Certificate Private Key (dCert')	Yes	RSA 2048-bit PKCS#1	Yes - at time of manufacture	No	N/A	Drive VPD	Non-volatile X.509 certificate signed with the IBM Tape root CA	Yes
Drive Session Public Key (dSK)	No	RSA 2048-bit PKCS#1	No – Generated by module	Yes	Non-approved, allowed in FIPS mode	Drive RAM	Ephemeral Plaintext	N/A
Drive Session Private Key (dSK')	Yes	RSA 2048-bit PKCS#1	No – Generated by module	No	Non-approved, allowed in FIPS mode	Drive RAM	Ephemeral Plaintext	Yes
Session Encrypted Data Key (SEDK)	No	RSA-2048 encrypted with the dSK	Yes	No	N/A	Drive RAM	Ephemeral Encrypted	Yes
Data Key (DK)	Yes	AES 256-bit symmetric key	Yes – (Received in encrypted form, encapsulated	No	N/A	Before Use: Drive RAM	Ephemeral Plaintext	Yes
			in the SEDK)			When in use: Stored In ASIC; (unreadab le register)	Ephemeral Encrypted form as SEDK	
186-2 PRNG Key	Yes	Seed	No – Generated by module	No	TRNG	Drive RAM	Ephemeral Plaintext	Yes
186-2 PRNG Seed	Yes	Seed (20 bytes)	No – Generated by module	No	TRNG	Drive RAM	Ephemeral Plaintext	Yes

Additional notes on key management:

- Secret and Private keys are never output from the LTO Gen4 drive in plaintext form.
- Secret and Private keys may only be imported to the LTO Gen4 drive in encrypted form.

3.6.3 Self-Test

The LTO Gen4 drive performs both Power On Self Tests and Conditional Self tests as follows.

The operator shall power cycle the device to invoke the Power On Self tests.

Table 8: Self-Tests

Function Tested	Self-Test Type	Implementation
AES-GCM	Power-Up	KAT performed for Encrypt and Decrypt
(256-bit keys)		(256-bit)
PRNG	Power-Up	KAT performed
SHA-1	Power-Up	KAT performed
SHA-256	Power-Up	KAT performed
RSA PKCS #1	Power-Up	KAT performed
Sign/Verify		
Software/Firmware	Power-Up	RSA PKCS #1 digital signature verification
Integrity Check drive		of PPC firmware; CRC check of SH vital
firmware		product data (VPD); CRC check of FPGA
PRNG	Conditional:	image. Ensure the newly generated random number
TRNO	When a random number is	does not match the previously generated
	generated using the approved	random number. Also ensure the first
	PRNG	number generated after start up is not used
	TRIVO	and is stored for the next comparison
TRNG (Custom)	Conditional:	Ensure the newly generated random number
TKNO (Custoiii)	When a random number is	does not match the previously generated
	generated using the non-	random number. Also ensure the first
	approved TRNG	number generated after start up is not used
	approved TRIVO	and is stored for the next comparison
Software/Firmware	Conditional:	RSA PKCS #1 signature verification of new
Load Check	When new firmware is loaded or	firmware image before new image may be
Load Circck	current firmware is re-booted	loaded
Seed and Seed key	Conditional:	Ensure that the XSeed and XKey values are
check	When seeding or re-seeding an	not equal for FIPS 186-2 generation.
	approved PRNG; TRNG is used	XKey and XSeed are generated from the
	for this purpose. (See TRNG	hardware TRNG, and compared on
	conditional self-test.)	instantiation of the PRNGs. If XKey is equal
	ĺ	to XSeed then they are regenerated until not
		equal.
Exclusive Crypto	Conditional:	Ensure the correct output of data after
Bypass Test	When switching between	switching modes
	encryption and bypass modes	Check to ensure the key is properly loaded
Key Path test	Conditional:	The drive will initiate a key request and key
-	When the Send Diagnostic	transfer operation with an attached Key
	command specifying this	Manager; random protected key material is
	diagnostic number is received	imported into the device and checked for
	from the host fibre or library	validity; status is reported back to the Key
	port; the drive must be unloaded	Manager and the invoking Host
	and idle or the command is	
	rejected	

3.6.4 Bypass States

The LTO Gen4 drive supports a single static bypass mode. Bypass entry, exit, and status features are provided to meet approved methods for use of bypass states.

Two independent internal actions are required to activate bypass mode. First, the LTO Gen4 drive checks the host interface on which the bypass request was received for transmission errors. Then the LTO Gen4 drive checks the settings in the Encryption Control 1 field of Mode Page X'25' to determine if the bypass capability is enabled.

3.7 Design Assurance

LTO Gen4 drive release parts are maintained under the IBM Engineering Control (EC) system. All components are assigned a part number and EC level and may not be changed without re-release of a new part number or EC level.

The following table shows the validated configuration for each host interfaces of the LTO Gen4 encrypting tape drive:

Table 9: Validated Configurations

IBM LTO Generation 4	Hardware	Hardware	Firmware Image
Encrypting Tape Drive	Part Number	EC Level	_
Ultra320 SCSI Drive	95P4613	H82642B	df080911bf_89Bb.SPI.fips.ro
Fibre Channel Drive	23R9539	H82590C	df080911bf_89Bb.FC.fips.ro
SAS Drive	23R9904	H82264	df080911bf_89Bb.SAS.fips.ro

3.8 Mitigation of other attacks

The LTO Gen4 drive does not claim to mitigate other attacks.